

# OPERATION MANUAL



## **WHISPERWATT™ SERIES MODEL DCA220SSJU4F 60Hz GENERATOR (JOHN DEERE 6068HFG09 DIESEL ENGINE)**

INSTRUCTION MANUAL NO. M5844300204

Revision #5 (09/23/25)

To find the latest revision of this publication or  
associated parts manual, visit our website at:

[www.mqpower.com](http://www.mqpower.com)



**THIS MANUAL MUST ACCOMPANY THE EQUIPMENT AT ALL TIMES.**

## PROPOSITION 65 WARNING

---



## **DCA220SSJU4F 60 Hz Generator**

Proposition 65 Warning .....	2
Table of Contents .....	3
Safety Decals .....	4
Safety Information .....	5–10
Specifications .....	11
Dimensions .....	12
Installation .....	13–14
General Information .....	15
General Paralleling Information (Option) .....	16–18
Major Components .....	19
Engine Controller Unit (ECU-835) .....	20
Engine/Generator Control Panel .....	21
Basler Digital Genset Controller (Option) .....	22–23
Paralleling Panel (Option) .....	24–25
Output Terminal Panel Familiarization .....	26–28
Load Application .....	29
PowerBalance® .....	30
Generator Outputs .....	31
Gauge Reading .....	32
Output Terminal Panel Connections .....	33–34
Inspection/Setup .....	35–39
Generator Start-Up Procedure (Manual) .....	40–42
Generator Start-Up Procedure (Auto Mode) .....	43
Generator Shutdown Procedure .....	44
Maintenance .....	45–59
Troubleshooting (Diagnostics) .....	60
Troubleshooting (Generator) .....	61
Troubleshooting (Engine) .....	62–63
Generator Wiring Diagrams .....	64–65
Engine Wiring Diagrams .....	66–68
Battery Charger Wiring Diagram (Option) .....	69
Engine Block Heater Wiring Diagram (Option) .....	70

### **DISCLAIMER:**

Product features, descriptions, and specifications are based on published information at the time of publication and are subject to change at any time without notice. Multiquip Inc. and its affiliates reserve the right to change specifications, features, design, and descriptions of products at any time without notice.

# SAFETY DECALS

Safety decals are attached to the generator as shown in Figure 1. Keep these safety decals clean at all times. When the safety decals become worn or damaged, contact your nearest dealer or the Multiquip Parts Department.

## NOTICE

For safety decal part numbers, refer to the associated parts manual.




Figure 1. Safety Decals

## SAFETY INFORMATION

Do not operate or service the generator before reading the entire manual. Safety precautions should be followed at all times when operating this generator. Failure to read and understand the safety messages and operating instructions could result in injury to yourself and others.








### SAFETY MESSAGES

The four safety messages shown below will inform you about potential hazards that could injure you or others. The safety messages specifically address the level of exposure to the operator and are preceded by one of four words: **DANGER**, **WARNING**, **CAUTION** or **NOTICE**.

### SAFETY SYMBOLS

 <b>DANGER</b>
Indicates a hazardous situation which, if not avoided, <b>WILL</b> result in <b>DEATH</b> or <b>SERIOUS INJURY</b> .
 <b>WARNING</b>
Indicates a hazardous situation which, if not avoided, <b>COULD</b> result in <b>DEATH</b> or <b>SERIOUS INJURY</b> .
 <b>CAUTION</b>
Indicates a hazardous situation which, if not avoided, <b>COULD</b> result in <b>MINOR</b> or <b>MODERATE INJURY</b> .
<b>NOTICE</b>
Addresses practices not related to personal injury.

Potential hazards associated with the operation of this generator will be referenced with hazard symbols which may appear throughout this manual in conjunction with safety messages.

Symbol	Safety Hazard
	Lethal exhaust gas hazards
	Explosive fuel hazards
	Burn hazards
	Overspeed hazards
	Rotating parts hazards
	Pressurized fluid hazards
	Electric shock hazards

# SAFETY INFORMATION

## GENERAL SAFETY

### ⚠ CAUTION

- **NEVER** operate this generator without proper protective clothing, shatterproof glasses, respiratory protection, hearing protection, steel-toed boots and other protective devices required by the job or city and state regulations.



- **NEVER** operate this generator when not feeling well due to fatigue or illness, or when on medication.
- **NEVER** operate this generator under the influence of drugs or alcohol.



- **ALWAYS** check the generator for loosened threads or bolts before starting.
- **NEVER** use the generator for any purpose other than its intended purposes or applications.

### NOTICE

- This generator should only be operated by trained and qualified personnel 18 years of age and older.
- Whenever necessary, replace nameplate, operation and safety decals when they become difficult to read.
- Manufacturer does not assume responsibility for any accident due to equipment modifications. Unauthorized modification of the generator will void all warranties.
- **NEVER** use accessories or attachments that are not recommended by MQ Power for this generator. Damage to the generator and/or injury to the user may result.
- **ALWAYS** know the location of the nearest fire extinguisher.
- **ALWAYS** know the location of the nearest first aid kit.



- **ALWAYS** know the location of the nearest phone or **keep a phone on the job site**. Also, know the phone numbers of the nearest **ambulance**, **doctor**, and **fire department**. This information will be invaluable in the case of an emergency.



## GENERATOR SAFETY

### ⚠ DANGER

- **NEVER** operate the generator in an explosive atmosphere or near combustible materials. An explosion or fire could result causing **severe bodily harm or even death**.



### ⚠ WARNING

- **NEVER** disconnect any **emergency or safety devices**. These devices are intended for operator safety. Disconnection of these devices can cause **severe injury, bodily harm or even death**. Disconnection of any of these devices will void all warranties.

### ⚠ CAUTION

- **NEVER** lubricate components or attempt service on a **running** generator.

### NOTICE

- **ALWAYS** ensure the generator is on level ground before use.
- **ALWAYS** keep the generator in proper running condition.
- Fix damage to the generator and replace any broken parts immediately.
- **ALWAYS** store the generator properly when it is not being used. The generator should be stored in a clean, dry location out of the reach of children and unauthorized personnel.

# SAFETY INFORMATION

## ENGINE SAFETY

### DANGER

- The engine fuel exhaust gases contain poisonous carbon monoxide. This gas is colorless and odorless, and can cause **death** if inhaled.
- The engine of this generator requires an adequate, free flow of cooling air. **NEVER** operate this equipment in any enclosed or narrow area where free flow of the air is restricted. If the air flow is restricted it will cause injury to people and property and serious damage to the equipment or engine.



- When operating the generator outdoors, **DO NOT** place the generator near doors, windows or vents that could allow carbon monoxide to enter and build up in occupied spaces.

### WARNING

- **NEVER** place hands or fingers inside the engine compartment when the engine is running.
- **NEVER** operate the engine with heat shields or guards removed.
- Keep fingers, hands, hair and clothing away from all moving parts to prevent injury.
- **NEVER** operate the generator with the doors open. Stop the engine before servicing.
- **DO NOT** remove the radiator cap while the engine is hot. High pressure boiling water will gush out of the radiator and severely scald any persons in the general area of the generator.
- **DO NOT** remove the coolant drain plug while the engine is hot. Hot coolant will gush out of the coolant tank and severely scald any persons in the general area of the generator.
- **DO NOT** drain the engine oil while the engine is hot. Hot oil will gush out and severely scald any persons near the generator.



- Operation of the generator may create sparks that can start fires around dry vegetation. A spark arrestor may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

### CAUTION

- **NEVER** touch the hot exhaust manifold, muffler or cylinder. Allow these parts to cool before servicing the generator.



### NOTICE

- **NEVER** run the engine without an air filter or with a dirty air filter. Severe engine damage may occur. Service the air filter frequently to prevent engine malfunction.
- **NEVER** tamper with the factory settings of the engine or engine governor. Damage to the engine or generator can result if operating in speed ranges above the maximum allowable.



- Wet stacking is a common problem with diesel engines which are operated for extended periods with light or no load applied. When a diesel engine operates without sufficient load (less than 30-35% of the rated output), it will not operate at its optimum temperature. This will allow unburned fuel to accumulate in the exhaust system, which can foul the fuel injectors, engine valves and exhaust system, including turbochargers, and reduce the operating performance.

In order for a diesel engine to operate at peak efficiency, it must be able to provide fuel and air in the proper ratio and at a high enough engine temperature for the engine to completely burn all of the fuel.

Wet stacking does not usually cause any permanent damage and can be alleviated if additional load is applied to relieve the condition. It can reduce the system performance and increase maintenance. Applying an increasing load over a period of time until the excess fuel is burned off and the system capacity is reached usually can repair the condition. This can take several hours to burn off the accumulated unburned fuel.

## SAFETY INFORMATION

### FUEL SAFETY

#### DANGER

- **NEVER** start the engine near spilled fuel or combustible fluids. Diesel fuel is extremely flammable and its vapors can cause an explosion if ignited.
- **ALWAYS** refuel in a well-ventilated area, away from sparks and open flames.
- **ALWAYS** use extreme caution when working with **flammable** liquids.
- **NEVER** fill the fuel tank while the engine is **running** or **hot**.
- **NEVER** overfill the fuel tank. Spilled fuel can ignite if it comes into contact with hot engine parts or sparks from the ignition system.
- Store fuel in appropriate containers, in well-ventilated areas and away from sparks and flames.
- **NEVER** use fuel as a cleaning agent.
- **NEVER** smoke around or near the equipment. Fire or explosion could result from fuel vapors or if fuel is spilled on a hot engine.



### TOWING SAFETY

#### CAUTION

- Check with your local county or state safety towing regulations, in addition to meeting **Department of Transportation (DOT) Safety Towing Regulations**, before towing your generator.
- Refer to the MQ Power trailer manual for additional safety information.
- In order to reduce the possibility of an accident while transporting the generator on public roads, **ALWAYS** make sure that the trailer that supports the generator and the towing vehicle are both mechanically sound and in good operating condition.
- **ALWAYS** shut down the engine before transporting.






- Make sure the hitch and coupling of the towing vehicle are rated equal to or greater than the trailer **gross vehicle weight rating**.
- **ALWAYS** inspect the hitch and coupling for wear. **NEVER** tow a trailer with defective hitches, couplings, chains, etc.
- Check the tire air pressure on both the towing vehicle and the trailer. **Inflate trailer tires as indicated on side wall of tire**. Also check the tire tread wear on both vehicles.
- **ALWAYS** make sure the trailer is equipped with **safety chains**.
- **ALWAYS** properly attach the trailer's safety chains to the towing vehicle.
- **ALWAYS** make sure the vehicle and trailer directional, backup, brake, and trailer lights are connected and working properly.
- DOT requirements include the following:
  - Connect and test electric brake operation.
  - Secure portable power cables in cable tray with tie wraps.
- The maximum speed for highway towing is **55 MPH** unless posted otherwise. Recommended off-road towing is not to exceed **15 MPH** or less depending on the type of terrain.
- Avoid sudden stops and starts. These can cause skidding or jackknifing. Smooth, gradual starts and stops will improve towing.
- Avoid sharp turns to prevent rolling.
- The trailer should be adjusted to a level position at all times when towing.
- Raise and lock the trailer wheel stand in the upright position when towing.
- Place **chock blocks** underneath the wheels to prevent **rolling** while parked.
- Place **support blocks** underneath the trailer's bumper to prevent **tipping** while parked.
- Use the trailer's swivel jack to adjust the trailer height to a level position while parked.



# SAFETY INFORMATION


## ELECTRICAL SAFETY

### DANGER

- **NEVER** touch the output terminals during operation. Contact with the output terminals during operation can cause **electrocution, electrical shock, or burn**. 
- The electrical voltage required to operate the generator can cause **severe injury or even death** through physical contact with live circuits. Turn the generator and all circuit breakers **OFF** before performing maintenance on the generator or making contact with the output terminals.
- **NEVER** insert any objects into the output receptacles during operation. This is extremely dangerous. The possibility exists of **electrical shock, electrocution or death**. 
- Backfeed to a utility system can cause **electrocution** and/or property damage. **NEVER** connect the generator to a building's electrical system without a transfer switch or other approved device. All installations should be performed by a **licensed electrician** in accordance with all applicable laws and electrical codes. Failure to do so could result in electrical shock or burn, causing **serious injury or even death**. 

## Power Cord/Cable Safety

### DANGER

- **NEVER** let power cords or cables **lay in water**.
- **NEVER** **stand in water** while AC power from the generator is being transferred to a load.
- **NEVER** use **damaged** or **worn** cables or cords when connecting equipment to the generator. Inspect the insulation for cuts.
- **NEVER** grab or touch a live power cord or cable with wet hands. The possibility exists of **electrical shock, electrocution or death**. 

- Make sure power cables are securely connected to the generator's output receptacles. Incorrect connections may cause electrical shock and damage to the generator.

### NOTICE

- **ALWAYS** make certain that the proper power or extension cord has been selected for the job. See the Cable Selection Chart in this manual.


## Grounding Safety

### DANGER


- **ALWAYS** make sure that electrical circuits are properly grounded to a suitable earth ground (ground rod) per the National Electrical Code (NEC) and local codes before operating the generator. **Severe injury or death by electrocution** can result from operating an ungrounded generator.
- **NEVER** use gas piping as an electrical ground.

## BATTERY SAFETY

### DANGER

- **DO NOT** drop the battery. There is a possibility that the battery will explode.
- **NEVER** expose the battery to open flames, sparks, cigarettes, etc. The battery contains combustible gases and liquids. If these gases and liquids come into contact with a flame or spark, an explosion could occur. 

### WARNING

- **ALWAYS** wear safety glasses when handling the battery to avoid eye irritation. The battery contains acids that can cause injury to the eyes and skin. 
- Use well-insulated gloves when picking up the battery.
- **ALWAYS** keep the battery charged. If the battery is not charged, combustible gas will build up.
- **ALWAYS** recharge the battery in a well-ventilated environment to avoid the risk of a dangerous concentration of combustible gases.
- If the battery liquid (dilute sulfuric acid) comes into contact with **clothing or skin**, rinse skin or clothing immediately with plenty of water.

# SAFETY INFORMATION

- If the battery liquid (dilute sulfuric acid) comes into contact with **eyes**, rinse eyes immediately with plenty of water and contact the nearest doctor or hospital to seek medical attention.

## CAUTION

- **ALWAYS** disconnect the **NEGATIVE** battery terminal before performing service on the generator.
- **ALWAYS** keep battery cables in good working condition. Repair or replace all worn cables.

## ENVIRONMENTAL SAFETY/DECOMMISSIONING

### NOTICE

Decommissioning is a controlled process used to safely retire a piece of equipment that is no longer serviceable. If the equipment poses an unacceptable and unrepairable safety risk due to wear or damage or is no longer cost effective to maintain (beyond life-cycle reliability) and is to be decommissioned (demolition and dismantlement), be sure to follow the rules below:

- **NEVER** pour waste or oil directly onto the ground, down a drain, or into any water source.
- Contact your country's Department of Public Works or recycling agency in your area and arrange for proper disposal of any electrical components, waste or oil associated with this equipment.
- When the life cycle of this equipment is over, remove the battery and bring it to an appropriate facility for lead reclamation. Use safety precautions when handling batteries that contain sulfuric acid.
- When the life cycle of this equipment is over, it is recommended that the frame and all other metal parts be sent to a recycling center.



Metal recycling involves the collection of metal from discarded products and its transformation into raw materials to use in manufacturing a new product.

Recyclers and manufacturers alike promote the process of recycling metal. Using a metal recycling center promotes energy cost savings.

## EMISSIONS INFORMATION

### NOTICE

The diesel engine used in this equipment has been designed to reduce harmful levels of carbon monoxide (CO), hydrocarbons (HC), and nitrogen oxides (NOx) contained in diesel exhaust emissions.

This engine has been certified to meet US EPA evaporative emissions requirements in the installed configuration.

Attempting to modify or make adjustments to the engine emission system by unauthorized personnel without proper training could damage the equipment or create an unsafe condition.

Additionally, modifying the fuel system may adversely affect evaporative emissions, resulting in fines or other penalties.

### Emission Control Label

The emission control label is an integral part of the emission system and is strictly controlled by regulations.

The label must remain with the engine for its entire life.

If a replacement emission label is needed, please contact your authorized engine distributor.

# SPECIFICATIONS

**Table 1. Generator Specifications**


<b>Model</b>	DCA220SSJU4F
<b>Type</b>	Revolving field, self-ventilated, open protected type synchronous generator
<b>Armature Connection</b>	<b>Star with Neutral</b>
<b>Phase</b>	3
<b>Standby Output</b>	194 kW (242 kVA)
<b>Prime Output</b>	176 kW (220 kVA)
<b>3Ø Voltage (L–L/L–N) Voltage Change-Over Board at 3Ø 240/139</b>	208Y/120, 220Y/127, 240Y/139
<b>3Ø Voltage (L–L/L–N) Voltage Change-Over Board at 3Ø 480/277</b>	416Y/240, 440Y/254, 480Y/277
<b>1Ø Voltage (L–L/L–N) Voltage Change-Over Board at 1Ø 240/120</b>	N/A
<b>Voltage Change-Over Board Tie Bolt Torque</b>	65.0 lbf·in (14.7 N·m)
<b>Power Factor</b>	0.8
<b>Frequency</b>	60 Hz
<b>Speed</b>	1,800 rpm
<b>Aux. AC Power</b>	Single phase, 60 Hz
<b>Aux. Voltage/Output</b>	4.8 kW (2.4 kW × 2)
<b>Dry Weight</b>	7,695 lb. (3,490 kg)
<b>Wet Weight</b>	8,489 lb. (3,850 kg)

**Table 2. Engine Specifications**

<b>Model</b>	John Deere 6068HF08 Tier 4 Final Certified	
<b>Type</b>	4-cycle, water-cooled, direct injection, turbo-charged charged air cooled, EGR, DOC, DPF and SCR	
<b>No. of Cylinders</b>	6	
<b>Bore × Stroke</b>	4.17 in. × 4.99 in. (106 mm × 127 mm)	
<b>Displacement</b>	415 cu. in. (6.8 liters)	
<b>Rated Output</b>	293 hp at 1,800 rpm	
<b>Starting</b>	Electric	
<b>Coolant Capacity</b>	10.3 gal. (39 liters) <sup>1</sup>	
<b>Lube Oil Capacity</b>	8.18 gal. (31 liters) <sup>2</sup>	
<b>Lube Oil Type</b>	API service class CJ-4, John Deere Plus-50 II	
<b>DEF Tank Capacity</b>	14.5 gal. (55 liters)	
<b>Fuel Tank Capacity</b>	68.6 gal. (260 liters)	
<b>Fuel Type</b>	#2 diesel fuel (ultra-low sulfur diesel fuel only)	
<b>Fuel Consumption</b>	12.5 gal. (47.1 L)/hr. at <b>full load</b>	9.7 gal. (36.4 L)/hr. at <b>3/4 load</b>
	6.9 gal. (26.1 L)/hr. at <b>1/2 load</b>	4.4 gal. (16.7 L)/hr. at <b>1/4 load</b>
<b>Battery</b>	12 (150Ah × 1)	

<sup>1</sup> Includes engine and radiator hoses

<sup>2</sup> Includes filters



## GENERATOR GROUNDING

**ALWAYS** refer to Article 250 (Grounding and Bonding) of the National Electrical Code (NEC).

### NOTICE

**ALWAYS** check with state, province, district, and municipalities for electrical grounding requirements before using the generator.

**EXAMPLE** of how to ground the unit (Figure 3) if the condition of use requires such a device:

## Connecting The Ground

Consult with local electrical and safety codes for proper connection based on condition of use. Refer to the Conductor Grounding Table, Article 250 of the NEC handbook.




Figure 3. Typical Generator Grounding Application

### NOTICE

Trailer-mounted generators are the sole responsibility of MQ Power.

## OUTDOOR INSTALLATION

Install the generator in an area that is free of debris, bystanders, and overhead obstructions. Make sure the generator is on secure, level ground so that it cannot slide or shift around. Also, install the generator in a manner so that the exhaust will not be discharged in the direction of nearby homes.

The installation site must be relatively free from moisture and dust. All electrical equipment should be protected from excessive moisture. Failure to do so will result in deterioration of the insulation and will result in short circuits and grounding.

Foreign materials such as dust, sand, lint, and abrasive materials have a tendency to cause excessive wear to engine and alternator parts.

### CAUTION

Pay close attention to ventilation when operating the generator inside tunnels and caves. The engine exhaust contains noxious elements. Engine exhaust must be routed to a ventilated area.

## INDOOR INSTALLATION

Exhaust gases from diesel engines are extremely poisonous. Whenever an engine is installed indoors the exhaust fumes must be vented to the outside. The engine should be installed at least two feet from any outside wall. Using an exhaust pipe which is too long or too small can cause excessive back pressure which will cause the engine to heat excessively and possibly burn the valves.

## MOUNTING

The generator must be mounted on a solid foundation (such as concrete) and set firmly on the foundation to isolate vibration of the generator when it is running. The generator must be mounted at least 6 inches above the floor or grade level as referenced in the National Fire Protection Association handbook (NFPA 110, Chapter 7, Section 7.4).

**DO NOT** remove the metal skids on the bottom of the generator. They are to resist damage to the bottom of the generator and to maintain alignment.

## GENERATOR

This generator is designed as a high-quality, portable (requiring a trailer for transport) power source for telecom sites, lighting facilities, power tools, submersible pumps, and other industrial and construction machinery.

## OPERATING PANEL

The “Operating Panel” is provided with the following:

- ECU 835 Controller (Standard)
- Gauge Unit Assembly
  - Oil Pressure Gauge
  - Water Temperature Gauge
  - Charging Voltmeter
  - Fuel Gauge
  - Tachometer
- Panel Light/Panel Light Switch
- Hour Check Button
- Auto Start/Stop Switch
- Emergency Stop Button
- Basler DGC-2020HD Digital Controller (Option)

## CONTROL PANEL

The “Control Panel” is provided with the following:

- Frequency Meter (Hz)
- AC Ammeter (Amps)
- AC Voltmeter (Volts)
- Ammeter Change-Over Switch
- Voltmeter Change-Over Switch
- Voltage Regulator
- 3-Pole, 600-amp, Main Circuit Breaker
- “Control Box” (located behind Control Panel)
  - Automatic Voltage Regulator
  - Current Transformer
  - Overcurrent Relay
  - Starter Relay
  - Voltage Change-Over Board

## OUTPUT TERMINAL PANEL

The “Output Terminal Panel” is provided with the following:

- Three 120/240V output receptacles (CS-6369), 50A
- Three auxiliary circuit breakers, 50A
- Two 120V output receptacles (GFCI), 20A
- Two GFCI circuit breakers, 20A
- Eight output terminal lugs (3Ø power)
- Ground Lug
- Battery Charger (Option)
- Cam-Loks (Option)
- Engine Block Heater (Option)

## OPEN-DELTA EXCITATION SYSTEM

Each generator is equipped with a state-of-the-art “Open-Delta” excitation system. The open-delta system consists of an electrically independent winding wound among stationary windings of the AC output section.

There are four connections of the open delta — A, B, C and D. During steady-state loads, the power from the voltage regulator is supplied from the parallel connections of A to B, A to D, and C to D. These three phases of the voltage input to the voltage regulator are then rectified and are the excitation current for the exciter section.

When a heavy load, such as a motor starting or a short circuit occurs, the automatic voltage regulator (AVR) switches the configuration of the open delta to the series connection of B to C. This has the effect of adding the voltages of each phase to provide higher excitation to the exciter section and thus better voltage response during the application of heavy loads.

The connections of the AVR to the AC output windings are for sensing only. No power is required from these windings.

The open-delta design provides virtually unlimited excitation current, offering maximum motor-starting capabilities. The excitation does not have a “fixed ceiling” and responds according to the demands of the required load.

## ENGINE

This generator is powered by a 6-cylinder, 4-cycle, water-cooled, direct-injection, turbocharged and cooled EGR John Deere 6068HFG09 diesel engine. This engine is designed to meet every performance requirement for the generator. Reference Table 2 for engine specifications. In keeping with MQ Power’s policy of constantly improving its products, the specifications quoted herein are subject to change without prior notice.

## ELECTRIC GOVERNOR SYSTEM

The electric governor system controls the RPM of the engine. When the engine demand increases or decreases, the governor system regulates the frequency variation to  $\pm 0.25\%$ .

## EXTENSION CABLES

When electrical power is to be provided to various tools or loads at some distance from the generator, extension cords are normally used. Cables should be sized to allow for distance in length and amperage so that the voltage drop between the generator and point of use (load) is held to a minimum. Use the cable selection chart (Table 7) as a guide for selecting proper extension cable size.



# GENERAL PARALLELING INFORMATION (OPTION)

## NOTICE

When the paralleling option is employed, the Basler DGC-2020HD controller **must** be installed. The factory installed ECU-835 controller cannot be used for paralleling.

## PARALLELING

Paralleling is the sharing of a load between two generator sets or more.

## LOAD SHARING

Load sharing is defined as the proportional division of the **kW** and **kVAR** total load between multiple generator sets in a paralleled system.

Load sharing is essential to avoid overloading and stability problems on the systems' generator sets.

## ACTIVE POWER (KW) LOAD SHARING

When generator sets operate in parallel, the engine speed governor of each generator set determines the proportional sharing of the total **active** power requirements (kW) of the systems.

The kW load sharing is achieved by increasing or decreasing fuel to the systems' engines. As the fuel to the engine of one generator set in a group is increased it will not lead to an increase in speed and hence frequency (as it would if it were operating alone) but it will lead to an increase in the proportion of the total kW load that it will deliver.

As the fuel to the engine of one generator set in a group is decreased it will not lead to a decrease in speed and hence frequency (as it would if it were operating alone) but it will lead to a decrease in the proportion of the total kW load that it will deliver.

The control system of the generator sets (via the engine speed control system) monitors and controls the sharing of the total kW load in proportion to the relative rating of the engines on the systems' generator sets.

## REACTIVE POWER (KVAR) LOAD SHARING

When generator sets operate in parallel, the **alternator field excitation** system of each generator set controls the proportional sharing of the total **reactive power requirements (kVAR)** of the system.

The kVAR load sharing is achieved by increasing or decreasing the field excitation to the systems' alternators.

As the field excitation of one generator set in a group is **increased** (i.e. over excited) it will **not** lead to an increase in voltage (as it would if it were operating alone) but it will lead to an increase in the proportion of the total **kVAR** load it will deliver and a decrease in its power factor.

As the field excitation of one generator set in a group is **decreased** (i.e. under excited) it will **not** lead to a decrease in voltage (as it would if it were operating alone) but it will lead to a decrease in the proportion of the total **kVAR** load it will deliver and an increase in its power factor.

An undesirable circulating **reactive current** (cross current) will flow in the system if the excitation of the alternators is not matched.

## ETHERNET COMMUNICATION

Ethernet communication is the preferred method for paralleling. This method supports breaker negotiation to avoid simultaneous breaker closures, kW load sharing and kVAR sharing, and soft load transfers on and off loading.

The Ethernet ports are located at the output bus splash panel area. There are two ports which are identical so either one can be used. Using a standard Ethernet cable, interconnect units to be paralleled and or sequenced.

## LOAD MANAGEMENT

These generators are set up to automatically manage load, based on demand. Load management is only functional in auto mode. While in **auto** mode, if the auto-start contacts are closed, load management is active by default. Load management will only run the number of units needed to support the load.

If the load demand is small, only one generator will remain running while the other generators will be in standby mode. If the load increases above 80% of its capacity, it will start the next generator. The next generator priority is based on the time remaining on the maintenance timer.

Generators with more time until scheduled maintenance will take priority over units that are almost due for maintenance. Once the second unit starts it will synchronize and parallel in, then ramp up to share the load. If the load levels drop below 35% of its combined rating, the generator that is no longer needed will ramp off, shut down and wait in standby mode.



# GENERAL PARALLELING INFORMATION (OPTION)

## SEQUENCING

### NOTICE

Ethernet communication is required when the generators are configured for the sequencing mode of operation.

These generators are capable of sequencing for control of balanced maintenance schedules. As described above, these generators can start and stop as demand increases or decreases. In addition, if a unit gets to the point of maintenance, it will ramp off and start the next generator to relieve it based on the time remaining on the maintenance timer.

After maintenance is performed, the maintenance timers should be reset to the recommended service interval. This is usually 250 hours depending on the engine oil type.

## MAINTENANCE INTERVAL

Maintenance intervals are factory set for 250 hours. The maintenance interval timer will count down to zero indicating that it is time for the unit to be serviced.

Once the timer counts down to zero, a pre-alarm will appear indicating that the unit is due for maintenance. To reset the maintenance interval back to the default time of 250 hours, press and hold the "Reset" button for ten seconds.

To reset the maintenance interval using the reset button, the Maintenance Due pre-Alarm must be active, and the Basler controller must display the "Overview Screen" (Main Screen).

If the maintenance timer has not yet expired and it is desired to reset the unit back to 250 hours, navigate back to the settings menu. Settings Menu->System Parameters->Engine Statistics->Hours To Maintenance.

## ALARM SILENCE

Pre-alarm Silence allows the user to suppress the toggling of the alarm screen when a new Pre-alarm becomes active. While a Pre-alarm is active, pressing the Alarm Silence button will suppress the fault display.

This happens to be very handy function when the "Maintenance Interval" Pre-Alarm occurs. Right after the Pre-Alarm occurs it will begin toggling between the **pre-alarm** and the **overview screen**.

While in this mode, pressing the reset button does not reset the maintenance interval. In order to reset the maintenance interval the overview screen **must** be selected.

Pressing the alarm silence button will stop the toggling between the pre-alarm and the overview screen.

Once the overview screen is selected, the maintenance interval can be reset by pressing and holding the reset button for 10 seconds.

## ANALOG LOAD SHARING

If no Ethernet cable is available or if paralleling to other equipment with traditional analog load sharing, there is a terminal block to connect a shielded wire pair between the two controls. The voltage ranges are programmable with the default value set by Multiquip at 0-3VDC, which is a common voltage for most controllers.

Please note that when in the load sharing mode the voltage is set to droop at 5%. This setting is programmable, but the default setting is 5%.

# GENERAL PARALLELING INFORMATION (OPTION)

## THREE-PHASE 480V/208V PARALLEL WIRING VIA OPTIONAL CAMLOCKS

### REQUIRED EQUIPMENT (USER SUPPLIED)

- Conductor Cables
- CAT5E Shielded Cable or Better
- Power Distribution Panel

The following procedure is intended to assist the user with the parallel wiring configuration for generators using the optional cam-lok connector panel.

#### NOTICE

Only a **qualified service technician** or **licensed electrician** with proper training should perform this installation. Follow all shop safety rules when performing this installation.

### PREPARATION

1. Make sure the generator is turned off and the engine is cool.
2. Disconnect any loads connected to the generator.
3. Place the main circuit breaker in the **OFF** position.
4. Place the generator in an area free of dirt and debris. Make sure it is on secure, level ground.
5. Disconnect the **negative** battery cable from the battery.

### 3Ø-480 VAC PARALLEL WIRING CONFIGURATION

Use appropriately sized cables when connecting two generators to the power distribution panel. Refer to the NEC handbook for correct sizing of cables. Contact a licensed electrician for correct electrical wiring configuration.

#### **! DANGER**

To prevent arcing make sure cables are securely tightened at the power distribution panel. The possibility exists of the unit catching on fire thus causing equipment damage and severe bodily harm.

#### NOTICE


When connecting load cables to the power distribution panel be sure to select the correct size of the load cables to handle full load/amperage of both generators (parallel).

### 3Ø-208 VAC PARALLEL WIRING CONFIGURATION

Use appropriately sized cables when connecting two generators to the power distribution panel. Refer to the NEC handbook for correct sizing of cables. Contact a licensed electrician for correct electrical wiring configuration.

### ETHERNET CABLE CONNECTION

1. Connect a CAT5E Ethernet cable (shielded) between port 1 on both generators as shown in Figure 4.



**Figure 4. Ethernet Cable Connection**

2. Refer to Table 4 for additional Ethernet port connections.

Table 4. Ethernet Cable Connections	
Generator 1	Generator 2
Port 2	Port 1
Port 1	Port 2
Port 2	Port 2

3. Reconnect the battery.
4. Start the generator as outlined in the start-up section of this manual.

# MAJOR COMPONENTS





Figure 5. Major Components




### Figure 6. Engine Control Unit (ECU)

The definitions below describe the controls and functions of the Engine Control Unit (Figure 6).

1. **ECU-835 Controller** — This auto start/stop controller displays the parameters and diagnostic troubleshooting messages of the engine, and controls DPF regeneration.
  - A. **ECU Display Screen** — Engine fault diagnostic messages are shown on this LCD display screen.
  - B. **Engine Started Lamp** — This lamp when lit indicates the engine is operating normally.
  - C. **Engine Shutdown Lamp** — When an engine failure has occurred this lamp will blink, indicating the engine has been shut down. The diagnostic fault message will be displayed on the LCD screen.
  - D. **Pre-Alarm Lamp** — When an engine failure has occurred this lamp will blink, indicating a pre-fault engine condition and the possibility of engine shutdown. The diagnostic fault message will be displayed on the LCD screen.
  - E. **Shutdown Lamp** — When an engine failure has occurred this lamp will start flashing. Pushing this button will confirm the fault message and the flashing lamp will change to a solid lamp display. The fault message will be displayed on the screen. When multiple engine faults occur, the lamp will continue flashing until all fault messages are confirmed. The flashing lamp will change to a solid lamp display and all current confirmed fault messages will scroll across the screen.
  - F. **Screen Change Button** — When this button is pressed during operation, the screen will cycle through each parameter screen.
  - G. **Option Button** — This button is not active. Do not use.
  - H. **Program/Exit Button** — Pressing this button allows the DPF Force Regen and diagnostic code to be confirmed.

# ENGINE/GENERATOR CONTROL PANEL



**Figure 7. Control Panel And Gauge Unit Assembly**

The definitions below describe the controls and functions of the Engine/Generator Control Panel (Figure 7).

1. **Gauge Unit Assembly** — This assembly houses the various engine monitoring gauges: oil pressure, water temperature, charging voltmeter, fuel level, and engine speed (tachometer).
  - A. **Oil Pressure Gauge** — During normal operation this gauge should read approximately 44 psi (303 kPa). When starting the generator the oil pressure may read a little higher, but after the engine warms up the oil pressure should return to the correct pressure range.
  - B. **Water Temperature Gauge** — During normal operation this gauge should read between 185° and 207°F (85°–97°C).
  - C. **Charging Voltmeter Gauge** — Indicates battery voltage. During normal operation this gauge should indicate a minimum of 14 V.
  - D. **Fuel Level Gauge** — Indicates the level of fuel in the fuel tank.
  - E. **Tachometer** — Indicates engine speed in RPM for 60 Hz operation. This meter should indicate 1,800 rpm when the rated load is applied.
2. **Panel Light** — For operation at night, the panel light illuminates the control panel for ease of reading meters and gauges.
3. **Panel Light Switch** — When activated will turn on the control panel light. Make sure the panel light switch is in the OFF position when the panel light is not needed.
4. **Frequency Meter** — Indicates the output frequency in hertz (Hz). Normally 60 Hz.
5. **AC Ammeter** — Indicates the amount of current the load is drawing from the generator per leg selected by the ammeter phase-selector switch.
6. **AC Voltmeter** — Indicates the output voltage present at the U, V, and W Output Terminal Lugs.
7. **Voltage Regulator Control** — Allows  $\pm 15\%$  manual adjustment of the generator's output voltage.
8. **Ammeter Change-Over Switch** — This switch allows the AC ammeter to indicate the current flowing to the load connected to any phase of the output terminals, or to be switched off. This switch does not affect generator output, it is for current reading only.
9. **Voltmeter Change-Over Switch** — This switch allows the AC voltmeter to indicate phase-to-phase voltage between any two phases of the output terminals or to be switched off.
10. **Emergency Stop Switch** — In the event of an emergency, press this button to shut down the generator.
11. **Auto Start/Stop Switch** — This switch selects either manual or automatic operation. Center position is **OFF** (reset).
12. **Hour Check Button** — With the engine stopped, press and hold this button. The total running hours, fuel level, and battery voltage will be displayed.
13. **Voltage Change-Over Board** — 6 jumper plates that allow the generator to be configured for either 240 or 480 VAC output.
14. **Main Circuit Breaker** — This three-pole, 600-amp main breaker is provided to protect the U, V, and W Output Terminal Lugs from overload.

## BASLER DIGITAL GENSET CONTROLLER (OPTION)




Figure 8. Basler DGC-2020HD

### NOTICE

The Basler DGC-2020HD controller is an **option**. It replaces the standard ECU-835 controller when the paralleling option is employed.



# BASLER DIGITAL GENSET CONTROLLER (OPTION)

---

The definitions below describe the controls and functions of the Digital Genset Controller (Figure 8).

1. **LCD Display** — Display consists of an LCD **color touch screen**. The backlit, 272 × 480-pixel color LCD serves as the local information source for metering, alarms, pre-alarms, and protective functions. Touch screen capability provides convenient navigation through metering and settings. Display operation is maintained down to -4°F (-20°C).
2. **Not In Auto Indicator** — This red LED lights when the DGC-2020HD is **not** operating in **Auto mode**.
3. **Alarm Indicator** — This red LED lights continuously during alarm conditions and flashes during pre-alarm conditions.
4. **Supplying Load Indicator** — This green LED lights when the generator current is greater than the emergency power supply (EPS) threshold current.
5. **Voltage Selection Indicators** — These three LEDs light to indicate the selected voltage. The **upper** lamp indicates **3-phase, 480-volt** operation. The **middle** lamp indicates **3-phase, 240-volt** operation. The **lower** lamp indicates **idle running** operation.
6. **Alarm Silence Pushbutton** — Press this button to open the relay output programmed as the horn output.
7. **Lamp Test Pushbutton** — Press this button to test the DGC-2020HD indicators by exercising all LCD pixels and lighting all LEDs.
8. **Auto Pushbutton and Mode Indicator** — Press the **Auto button** to place the DGC-2020HD in **Auto mode**. The green **Auto Mode LED** lights when Auto mode is active.

While in Auto mode, if the unit's auto-start contacts are connected to a transfer switch and the contacts between the terminals are closed, the unit will start and automatically close the circuit breaker.

If running in parallel, the Basler controller will command the unit to start and close the breaker based on load demand. If a failure occurs with another generator in the paralleled system, the controller will start and synchronize, then close the motorized breaker to electrically lock the unit in parallel.

If the bus is dead it will immediately close the circuit breaker to provide power to the load(s). If the bus is already hot from another generator it will first synchronize, then close its breaker, then slowly ramp up to share load if load is present.

9. **Off Pushbutton and Mode Indicator** — Press this button to place the DGC-2020HD in **Off mode**. The red **Off Mode LED** lights whenever the DGC-2020HD is in Off mode.
10. **Run Pushbutton and Mode Indicator** — Press this button to place the DGC-2020HD in **Run mode**. The green **Run Mode LED** lights whenever Run mode is active.
11. **Reset Pushbutton** — Press this button to cancel a settings editing session and discard any settings changes. When held, this button resets the **Breaker Management pre-alarms**. This button is also used to reset the maintenance interval when pressed for 10 seconds while viewing **Hours Until Maintenance** or the **Maintenance Due pre-alarm**.
12. **Arrow Pushbuttons** — These four buttons are used to navigate through the front panel display menus and to modify settings.
  - The **Left Arrow and Right Arrow buttons** are used to navigate through the menu levels. Press the **Right Arrow button** to move **downward** through the menu levels and press the **Left Arrow button** to move **upward** through the menu levels.
  - The **Up Arrow and Down Arrow buttons** are used to move among items within a menu level. Press the **Down Arrow button** to move to items lower on the list. Press the **Up Arrow button** to move to items higher on the list.
  - During a settings editing session, the Up Arrow and Down Arrow buttons are used to increase and decrease the value of the selected setting. The Right Arrow and Left Arrow buttons move to different digits.
13. **Edit Pushbutton** — Press the **Edit pushbutton** to start an editing session and enable changes to the DGC-2020HD settings. At the conclusion of an editing session, press this button again to save the setting changes.

## PARALLELING PANEL (OPTION)




Figure 9. Paralleling Panel Components



## PARALLELING PANEL (OPTION)

The definitions below describe the controls and functions of the Paralleling Panel (Figure 9).

1. **Panel Lights** — For operation at night or in dark areas, the panel lights illuminate the paralleling panel for ease of reading.
2. **Panel Light Switch** — When activated will turn on the control panel lights.
3. **Voltage Adjust Potentiometer** — The **voltage adjust potentiometer** is a way to adjust the voltage up or down for fine tuning. The adjustment sends a signal to the controller to offset the system rated voltage (trim voltage). It is important that all machines are set to the same value when paralleling.

When first turning on the control power, the controller will begin its boot sequence much like a computer does. After completing the boot sequence the unit will be ready to run or be placed in auto for auto-start applications.

4. **Control Power Toggle Switch** — The control power switch is a master power switch for the digital controller. The control power switch has a latch feature that prevents powering down control power while the engine is running.
5. **Emergency Stop Button Switch** — The Emergency Stop pushbutton switch is used to stop the engine in case of emergency or to lock out operation during service. The emergency stop button ***should not be used for routine stopping of the engine.***

Actuation of the Emergency stop button while the control power is on will illuminate the light on the button as well as display “Emergency Stop” on the controller display. Actuating the Emergency stop button will de-energize all controller outputs and cause the engine to stop as well as trip the circuit breaker. This condition is a latched condition that must be reset prior to restarting the engine.

The procedure for resetting the emergency stop requires several actions. Rotate the emergency stop button to release the spring latch. To clear the latch, the controller must be placed in the off mode by pressing the “OFF” button. While in the “OFF” mode, the “RESET” button must be pressed to clear the E-STOP fault.

For units with manually operated breakers, the breaker will need to be reset by toggling the handle down, then can be turned back to the “ON” position. On models with spring-charged breakers resetting the breaker is not necessary.

6. **Contactor Operation (Manual Mode)** — For manual run applications, user action is required to get the generator power to the output bus. Depending on the model, some utilize contactors in series with toggle-handle circuit breakers and others have spring-charged automatic circuit breakers.

On the spring-charged types, the buttons on the breaker itself are not intended for circuit breaker operation. For instructional purposes both will be referred to as “contactor.”

There are two pushbuttons on the control panel for controlling the contactor. There is a green “CLOSE CONTACTOR” button to close the contactor and a red “OPEN CONTACTOR” button to open the contactor. These buttons illuminate to show the contactor status. If the contactor is open, the red “OPEN CONTACTOR” button will be illuminated. If the contactor is closed the green “CLOSE CONTACTOR” button will be illuminated.

These buttons can sometimes be multifunctional depending on the situation. For stand-alone operation the buttons simply close and open the contactor as expected. For paralleling the buttons can act a little different.

When the bus is already hot from another generator, pressing the green online button will initiate a synchronizing sequence before closing the contactor. There will be an image of a synchroscope on the controller display and when the voltage and phases are matched, the contactor will close.

If there was already load on the bus the unit will slowly ramp up load until it is sharing equally with the other generator(s). While sharing load with other generators, pressing the red “OPEN CONTACTOR” button once will initiate a ramp-down sequence. The unit will begin to ramp down and when at a low level of load it will automatically open its contactor. Pressing the red “OPEN CONTACTOR” button twice will immediately open the contactor.

# OUTPUT TERMINAL PANEL FAMILIARIZATION

## OUTPUT TERMINAL PANEL

The Output Terminal Panel (Figure 11) shown below is provided for the connection of electrical loads. Lift up on the cover to gain access to receptacles and terminal lugs.

### NOTICE

**Terminal O** is **neutral bonded** to the ground from the factory.

### NOTICE

Output Terminal Bolt Torque: 554.9 lbf-in (62.7 N·m)

## OUTPUT TERMINAL FAMILIARIZATION

The Output Terminal Panel is provided with the following:

- Three (3) 240/139V output receptacles @ 50 amps
- Three (3) circuit breakers @ 50 amps
- Two (2) 120V GFCI receptacles @ 20 amps
- Two (2) GFCI circuit breakers @ 20 amps
- Eight (8) Output terminal lugs (U, V, W, O, Ground)




Figure 10. Output Terminal Panel

# OUTPUT TERMINAL PANEL FAMILIARIZATION

## 120 VAC GFCI Receptacles

### NOTICE

It is recommended that the GFCI receptacles be tested when the generator is initially uncrated. The receptacles should then be tested daily at startup.

There are two 120 VAC, 20-amp, GFCI (duplex Nema 5-20R) receptacles provided on the output terminal panel. These receptacles can be accessed in any **voltage change-over board** position. Each receptacle is protected by a 20-amp circuit breaker. These breakers are located directly above the GFCI receptacles. Remember the load output (current) of both GFCI receptacles is dependent on the load requirements of the U, V, and W output terminal lugs.

Press the **reset** button to reset the GFCI receptacle after it has been tripped. Press the **test button** (Figure 11) in the center of the receptacle to check the GFCI function. Both receptacles should be tested at least once a month. Refer to the **Maintenance** section in this manual for further testing of the GFCI receptacle.




Figure 11. GFCI Receptacle

## Twist-Lock Dual-Voltage 240/139-Volt AC Receptacles

There are three 240/139-volt, 50-amp, auxiliary twist-lock (CS6369) receptacles (Figure 12) provided on the output terminal panel. For 240/139-volt usage, these receptacles can be used at any time during operation. For 208/120-volt usage:

- With the voltage change-over board configured for 480-volt output, use the voltage regulator to adjust the output voltage to 416V, or

- With the voltage change-over board configured for 240-volt output, use the voltage regulator to adjust the output voltage to 208V.




Figure 12. 240/139-Volt Twist-Lock  
Auxiliary Receptacles

Each auxiliary receptacle is protected by a 50-amp circuit breaker. These breakers are located directly above the GFCI receptacles. Remember the load output (current) on all three receptacles is dependent on the load requirements of the **output terminal lugs**.

## Removing The Plastic Face Plate (Hard Wire Hookup Panel)

The output terminal lugs are protected by a plastic face plate cover (Figure 13). Unscrew the securing bolts and lift the plastic terminal cover to gain access to the terminal enclosure.

After the load wires have been securely attached to the terminal lugs, reinstall the plastic face plate.




Figure 13. Plastic Face Plate  
(Output Terminal Lugs)

# OUTPUT TERMINAL PANEL FAMILIARIZATION

## Connecting Loads

Loads can be connected to the generator by the output terminal lugs, convenience receptacles, or optional cam-locks (Figure 14). Make sure to read the operation manual before attempting to connect a load to the generator.

To protect the output terminals from overload, a 3-pole, 600-amp, **main** circuit breaker is provided. Make sure to switch **ALL** circuit breakers to the **OFF** position prior to starting the engine.




Figure 14. Connecting Loads

## Overcurrent Relay

An **overcurrent relay** (Figure 15) is connected to the main circuit breaker. In the event of an overload, both the circuit breaker and the overcurrent relay may trip. If the circuit breaker cannot be reset, the **reset button** on the overcurrent relay must be pressed. The overcurrent relay is located inside the control box.




Figure 15. Overcurrent Relay

### NOTICE

The **overcurrent relay** monitors the current flowing from the **U, V, and W Output Terminal Lugs** to the load.

In the event of a short circuit or overcurrent condition, the overcurrent relay will automatically trip the 600-amp main breaker.

To restore power to the **Output Terminal Panel**, press the reset button on the overcurrent relay and place the **main circuit breaker** in the **closed** position (**ON**).

# LOAD APPLICATION

## SINGLE-PHASE LOAD

Always be sure to check the nameplate on the generator and equipment to ensure the wattage, amperage, frequency, and voltage requirements are satisfactorily supplied by the generator for operating the equipment.

Generally, the wattage listed on the nameplate of the equipment is its rated output. Equipment may require 130–150% more wattage than the rating on the nameplate, as the wattage is influenced by the efficiency, power factor and starting system of the equipment.

### NOTICE

If wattage is not given on the equipment's nameplate, approximate wattage may be determined by multiplying the nameplate voltage by the nameplate amperage.

$$\text{WATTS} = \text{VOLTAGE} \times \text{AMPERAGE}$$

The power factor of this generator is 0.8. See Table 6 below when connecting loads.

**Table 6. Power Factor By Load**

Type of Load	Power Factor
Single-phase induction motors	0.4–0.75
Electric heaters, incandescent lamps	1.0
Fluorescent lamps, mercury lamps	0.4–0.9
Electronic devices, communication equipment	1.0
Common power tools	0.8

**Table 7. Cable Selection (60 Hz, Single-Phase Operation)**

Current in Amperes	Load in Watts		Maximum Allowable Cable Length			
	At 100 Volts	At 200 Volts	#10 Wire	#12 Wire	#14 Wire	#16 Wire
2.5	300	600	1,000 ft.	600 ft.	375 ft.	250 ft.
5	600	1,200	500 ft.	300 ft.	200 ft.	125 ft.
7.5	900	1,800	350 ft.	200 ft.	125 ft.	100 ft.
10	1,200	2,400	250 ft.	150 ft.	100 ft.	
15	1,800	3,600	150 ft.	100 ft.	65 ft.	
20	2,400	4,800	125 ft.	75 ft.	50 ft.	

CAUTION: Equipment damage can result from low voltage.

## THREE-PHASE LOAD

When calculating the power requirements for 3-phase power use the following equation:

$$\text{KVA} = \frac{\text{VOLTAGE} \times \text{AMPERAGE} \times 1.732}{1000}$$

### NOTICE

If 3Ø load (kVA) is not given on the equipment nameplate, approximate 3Ø load may be determined by multiplying voltage by amperage by 1.732.

### NOTICE

Motors and motor-driven equipment draw much greater current for starting than during operation.


An inadequately sized connecting cable which cannot carry the required load can cause a voltage drop which can burn out the appliance or tool and overheat the cable. See Table 7.

- When connecting a resistance load such as an incandescent lamp or electric heater, a capacity of up to the generating set's rated output (kW) can be used.
- When connecting a fluorescent or mercury lamp, a capacity of up to the generating set's rated output (kW) multiplied by 0.6 can be used.
- When connecting an electric drill or other power tools, pay close attention to the required starting current capacity.
- When connecting ordinary power tools, a capacity of up to the generating set's rated output (kW) multiplied by 0.8 can be used.

### DANGER

Before connecting this generator to any building's electrical system, a **licensed electrician** must install an **isolation (transfer) switch**. Serious damage to the building's electrical system may occur without this transfer switch.

**PowerBalance®** (Figure 16) is an optional load management solution that helps protect the engine generator from problems resulting from sustained low-load operations (defined as less than 30% of the generator full-load rating).



**Figure 16. PowerBalance®**

- PowerBalance® continuously monitors engine load. The load management controller senses and increases engine load automatically using resistive coils when the controller determines that the temperature and/or load is too low.
- When additional load demands are placed on the generator that bring it to an optimum level, PowerBalance® will automatically deactivate this additional load and remain ready for reactivation should exhaust temperatures drop.



# GENERATOR OUTPUTS

## GENERATOR OUTPUT VOLTAGES

A wide range of voltages (Table 8) is available for many different applications.

Table 8. Voltages Available						
UVWO Output Terminal Lugs	Voltage Change-Over Board 3-Phase 240/139V Position			Voltage Change-Over Board 3-Phase 480/277V Position		
3Ø Line-Line	208V	220V	240V	416V	440V	480V
3Ø Line-Neutral	120V	127V	139V	240V	254V	277V

## Voltage Change-Over Board

Select output voltage by applying six jumper plates to the **voltage change-over board** (Figure 17), which is located inside the control box behind the generator control panel. This board has been provided for ease of voltage selection.




Figure 17. Voltage Change-Over Board

### WARNING

**NEVER** attempt to place jumper plates on the **voltage change-over board** while the generator is in operation. There exists the possibility of **electrocution, electrical shock, or burn, which can cause severe bodily harm or even death!**

### NOTICE

Make sure the tie bolts securing the voltage change-over board bus bars are **secure** and **tight**. The possibility exists of arcing that could cause a fire. Torque bolts to 65.0 lbf·in (14.7 N·m).

## Voltage Regulator

To obtain some of the voltages listed in Table 8 will require a fine voltage adjustment using the **voltage regulator** (Figure 18) located on the control panel.




Figure 18. Voltage Regulator

## Maximum Amps

Table 9 shows the **maximum** amps the generator can provide. **DO NOT** exceed the maximum amps as listed.

Table 9. Generator Maximum Amps	
Rated Voltage	Maximum Amps
1Ø 120 Volts	488.9 × 2 amps (4 wire)
1Ø 240 Volts	244.4 amps (4 wire)
3Ø 240 Volts	529 amps
3Ø 480 Volts	264 amps
Main Line Circuit Breaker Rating	600 amps
Overcurrent Relay Trip Set Point 480V Mode Only	256 amps

## GAUGE READING

### HOW TO READ THE AC AMMETER AND AC VOLTMETER GAUGES

The AC ammeter and AC voltmeter gauges are controlled by the AC ammeter and AC voltmeter change-over switches.

Both of these switches are located on the control panel and **DO NOT** affect the generator output. They are provided to help observe how much power is being produced at the UVWO terminal lugs.

Before taking a reading from either gauge, configure the **Voltage Change-Over Board** (Figure 19) for the desired output voltage.

#### NOTICE

Make sure the tie bolts securing the voltage change-over board bus bars are **secure** and **tight**. The possibility exists of arcing that could cause a fire. Torque bolts to 65.0 lbf·in (14.7 N·m).




Figure 19. Voltage Change-Over Board  
240V Position

### AC Voltmeter Gauge Reading

Place the **AC Voltmeter Change-Over Switch** (Figure 20) in the W-U position and observe the phase-to-phase voltage reading between the W and U terminals as indicated on the **AC Voltmeter Gauge** (Figure 21).




Figure 20. AC Voltmeter  
Change-Over Switch




Figure 21. AC Voltmeter Gauge  
(Volt Reading On W-U Lug)

### AC Ammeter Gauge Reading

Place the **AC Ammeter Change-Over Switch** (Figure 22) in the U position and observe the current reading (load drain) on the U terminal as indicated on the **AC Ammeter Gauge** (Figure 23). This process can be repeated for terminals V and W.




Figure 22. AC Ammeter  
Change-Over Switch




Figure 23. AC Ammeter  
(Amp Reading On U Lug)

#### NOTICE

The **ammeter** gauge will only show a reading when the **output terminal lugs** are connected to a load and in use.



# OUTPUT TERMINAL PANEL CONNECTIONS

## UVWO TERMINAL OUTPUT VOLTAGES

Various output voltages can be obtained using the UVWO output terminal lugs. The voltages at the terminals are dependent on the placement of the jumper plates (6) on the **Voltage Change-Over Board** and the adjustment of the **Voltage Regulator**.

The voltage change-over board determines the **range** of the output voltage and can be configured in two different positions that provide 6 different output voltages at the UVWO output terminals. The generator is shipped from the factory in the 240V configuration. The voltage regulator (VR) allows the user to increase or decrease the selected voltage.

### NOTICE

Make sure the tie bolts securing the voltage change-over board bus bars are **secure** and **tight**. The possibility exists of arcing that could cause a fire. Torque bolts to 65.0 lbf·in (14.7 N·m).

### NOTICE

**ALWAYS** make sure that the connections to the UVWO terminals are **secure** and **tight**. The possibility exists of arcing that could cause a fire. Torque tie bolts to 554.9 lbf·in (62.7 N·m).

## 3Ø-240V UVWO Terminal Output Voltages

1. Jumper the voltage change-over board for 240V operation as shown in Figure 24.




Figure 24. Voltage Change-Over Board  
3Ø 240/139V Configuration

2. Connect the load wires to the UVWO terminals as shown in Figure 25.




Figure 25. UVWO Terminal Lugs  
3Ø-240V/1Ø-139V Connections

3. Turn the voltage regulator (Figure 26) clockwise to increase voltage output, and turn counterclockwise to decrease voltage output. Use the voltage regulator whenever fine tuning of the output voltage is required.



Figure 26. Voltage Regulator

## 1Ø-240V UVWO Terminal Output Voltages

1. Make sure the voltage change-over board is jumpered for 240V operation as shown in Figure 24.
2. Connect the load wires to the UVWO terminals as shown in Figure 27.





Figure 27. UVWO Terminal Lugs  
1Ø-240V Connections

# OUTPUT TERMINAL PANEL CONNECTIONS

## 1Ø-120V UVWO Terminal Output Voltages


1. Make sure the voltage change-over board is jumpered for 240V operation as shown in Figure 24.
2. Adjust the voltage regulator (Figure 26) for an output of 208V to obtain 120V at the UVWO terminals.
3. Connect the load wires to the UVWO terminals as shown in Figure 28.



**Figure 28. UVWO Terminal Lugs  
1Ø-120V Connections**


## 3Ø-480V UVWO Terminal Output Voltages

1. Jumper the voltage change-over board for 480V operation as shown in Figure 29. This configuration uses 6 jumper plates in 3 different positions. Remember there are 2 jumper plates at every position. Every jumper plate **must** be used.



**Figure 29. Voltage Change-Over Board  
3Ø 480/277V Configuration**


2. Connect the load wires to the UVWO terminals as shown in Figure 30.



**Figure 30. UVWO Terminal Lugs  
3Ø-480V Connections**

## 1Ø-480V UVWO Terminal Output Voltages


1. Make sure the voltage change-over board is jumpered for 480V operation as shown in Figure 29.
2. Connect the load wires to the UVWO terminals as shown in Figure 31.



**Figure 31. UVWO Terminal Lugs  
1Ø-480V Connections**

## 1Ø-277V UVWO Terminal Output Voltages


1. Make sure the voltage change-over board is jumpered for 480V operation as shown in Figure 29.
2. Connect the load wires to the UVWO terminals as shown in Figure 32.



**Figure 32. UVWO Terminal Lugs  
1Ø-277V Connections**


## ENGINE OIL CHECK

1. To check the engine oil level, place the generator on secure, level ground with the engine stopped.
2. Remove the dipstick from its holder (Figure 33) and wipe it clean.



**Figure 33. Engine Oil Dipstick Location**

3. Reinsert the dipstick, then remove the dipstick from its holder. Check the oil level shown on the dipstick (Figure 34).




**Figure 34. Engine Oil Dipstick Level**

4. Verify that the engine oil level is maintained between the **H** and **L** markings on the dipstick as shown in Figure 34A.
5. If the engine oil level is low (Figure 34C), remove the cap from the oil filler port (Figure 35) and fill to a safe operating level (max) as indicated by the dipstick (Figure 34A). Fill with the recommended oil type as listed in Table 10. Maximum oil capacity is 8.18 gallons (31 liters).

### NOTICE

When adding engine oil, **DO NOT** overfill (Figure 34B).



**Figure 35. Engine Oil Filler Port**

**Table 10. Recommended Motor Oil**

		OIL: SAE	
°F	°C		
122	50		
104	40	10W/40	30
86	30		
68	20	10W/40	15W/30
50	10		
32	0	5W/30	10W/30
-14	-10	ARCTIC OIL	10W
-4	-20		
-22	-30		
-40	-40		

## FUEL CHECK

### DANGER



Fuel spillage on a **hot** engine can cause a **fire** or **explosion**. If fuel spillage occurs, wipe up the spilled fuel completely to prevent fire hazards. **NEVER** smoke around or near the generator.

### NOTICE

**ALWAYS** check the DEF tank level when adding fuel.

## Refilling The Fuel System

### NOTICE

**DO NOT** refuel while the engine is running.


### CAUTION

**ONLY** properly trained personnel who have read and understand this section should refill the fuel tank system.

When equipped with a trailer or skid, the generator may have a **double fuel tank system** (Figure 36), which consists of an **internal fuel tank** and a **trailer-mounted fuel tank**.

**ALWAYS** fill the fuel tank with clean, fresh, **#2 diesel fuel**. Pay attention to the fuel tank capacity when replenishing fuel. **DO NOT** fill the fuel tank beyond its capacity.

Close the **fuel filler cap** (Figure 36) tightly after filling. Handle fuel in a safety container. If the container does not have a spout, use a funnel. Wipe up any spilled fuel **immediately**.



**Figure 36. Double Fuel Tank System**

## Refueling Procedure

### WARNING




**Diesel fuel** and its vapors are dangerous to your health and the surrounding environment. Avoid inhalation of fumes and contact with skin.

1. **Level Tanks** — Make sure fuel cells are level with the ground. Failure to do so will cause fuel to spill from the tank before reaching full capacity (Figure 37).

### CAUTION

**ALWAYS** place the trailer on firm, level ground before refueling to prevent spilling and to maximize the amount of fuel that can be added to the tank.




**Figure 37. Only Fill On Level Ground**

### NOTICE

**ONLY** use **#2 diesel fuel** (ultra-low sulfur diesel fuel) when refueling.

2. Remove the fuel cap and fill the tank as shown in Figure 38.



**Figure 38. Fueling The Generator**

3. **NEVER overfill the fuel tank** — It is important to read the fuel gauge when filling the trailer fuel tank. **DO NOT** wait for fuel to rise inside the filler neck (Figure 39).

FUEL GAUGE LOCATED  
ON GAUGE UNIT ASSEMBLY




Figure 39. Full Fuel Tank

## CAUTION

**DO NOT OVERFILL** the fuel system. Leave room for fuel expansion. Fuel expands when heated (Figure 40).



Figure 40. Fuel Expansion

## DIESEL EXHAUST FLUID

Diesel exhaust fluid is an aqueous solution made with 32.5% high-purity urea (carbamide) and 67.5% deionized water. DEF is used as a consumable in selective catalytic reduction (SCR) in order to lower NO<sub>x</sub> concentration from diesel exhaust emissions.

**ALWAYS** check the DEF level when refueling. Before initial start-up, completely fill the DEF tank with DEF fluid. **DO NOT** overfill.




Figure 41. Filling The DEF Tank

## DEF Refilling

### NOTICE

**ONLY** fill the DEF tank with **diesel exhaust fluid**. Any other type of fluid may cause severe engine damage.

1. Make sure the engine is **OFF**.
2. Remove the DEF tank filler cap (Figure 41).
3. Add diesel exhaust fluid to the tank. **DO NOT** overfill.
4. Reinstall the DEF tank cap. Tighten securely.

## DEF Refilling (Continuous Operation)

It is recommended to **shut down the engine** prior to refilling the DEF tank. However, during special applications where shutdown is not possible, it is recommended to **ONLY** refill the DEF tank when the fluid level has been consumed down to 50%.

The DEF level sending unit requires a gradual DEF level decrease during continuous operation to validate proper operation. Failure of this sensor to report the decrease could result in an engine shutdown. An engine service technician would be required to remedy the shutdown.

## COOLANT

### (ANTIFREEZE/SUMMER COOLANT/WATER)

John Deere recommends Cool-Gard II antifreeze/summer coolant for use in their engines, which can be purchased in concentrate (and mixed with 50% demineralized water) or pre-diluted. See the **John Deere Engine Owner's Manual** for further details.

## WARNING



When adding coolant/antifreeze mix to the radiator, **DO NOT** remove the radiator cap until the unit has completely cooled. The possibility of **hot!** coolant exists which can cause **severe burns**.

Day-to-day addition of coolant is done from the reserve tank. When adding coolant to the radiator, **DO NOT** remove the radiator cap until the unit has completely cooled. See Table 11 for engine/radiator and reserve tank coolant capacities.


**Table 11. Coolant Capacity**

Engine and Radiator	10.3 gal. (39 liters)
Reserve Tank	See markings

## NOTICE

Normally, only the coolant level in the reserve tank needs to be checked. However, the radiator cap should be opened once a week to verify that coolant is visible (full) inside the radiator.

Verify that the coolant level in the coolant reserve tank is between the **MAX** and **MIN** markings as shown in Figure 42.



**Figure 42. Coolant Reserve Tank**

## Operation In Freezing Weather

When operating in freezing weather, be certain the proper amount of antifreeze (Table 12) has been added.

**Table 12. Antifreeze Operating Temperatures**

Vol. % Antifreeze	Freezing Point	
	°C	°F
50	-37	-34

## NOTICE

When the antifreeze is mixed with water, the antifreeze mixing ratio **must be** less than 50%.

## Cleaning The Radiator

The engine may overheat if the radiator fins become overloaded with dust or debris. Periodically clean the radiator fins with compressed air. Cleaning inside the machine is dangerous, so clean only with the engine turned off and the **negative** battery terminal disconnected.

## ENGINE AIR CLEANER

Periodic cleaning and replacement of the engine air cleaner is necessary. Inspect the air cleaner in accordance with the **John Deere Engine Owner's Manual**.

## FAN BELT TENSION

The engine fan belt is automatically tensioned and does not require adjustment.

## CAUTION



**NEVER** place hands near the belts or fan while the generator set is running.

## BATTERY

This unit is of negative ground. **DO NOT** connect in reverse. Always maintain battery fluid level between the specified marks. Battery life will be shortened if the fluid level is not properly maintained. Add only distilled water when replenishment is necessary.

**DO NOT** overfill. Check to see whether the battery cables are loose. Poor contact may result in poor starting or malfunctions. **ALWAYS** keep the terminals firmly tightened. Coat the terminals with an approved battery terminal treatment compound. Replace the battery with only the recommended type battery. The battery type used in this generator is BCI Group 4D.

The battery is sufficiently charged if the specific gravity of the battery fluid is 1.28 (at 68°F). If the specific gravity should fall to 1.245 or lower, it indicates that the battery is dead and needs to be recharged or replaced.

Before charging the battery with an external electrical source, be sure to disconnect the battery cables.




## Battery Cable Installation

**ALWAYS** be sure the battery cables (Figure 43) are properly connected to the battery terminals as shown below. The **red cable** is connected to the positive terminal of the battery, and the **black cable** is connected to the negative terminal of the battery.

### CAUTION

**ALWAYS** disconnect the negative terminal first and reconnect the negative terminal last.



**Figure 43. Battery Connections**

When connecting the battery, do the following:

1. **NEVER** connect the battery cables to the battery terminals when the **Auto Start/Stop switch** is in either the **AUTO** or **MANUAL** position. **ALWAYS** make sure that this switch is in the **OFF/RESET** position when connecting the battery.
2. Place a small amount of battery terminal treatment compound around both battery terminals. This will ensure a good connection and will help prevent corrosion around the battery terminals.

### NOTICE

If the battery cables are connected incorrectly, electrical damage to the generator will occur. Pay close attention to the polarity of the battery when connecting the battery.

### CAUTION

Inadequate battery connections may cause poor starting of the generator and other malfunctions.

## ALTERNATOR

The polarity of the alternator is negative grounding type. When an inverted circuit connection takes place, the circuit will be in short circuit instantaneously resulting in alternator failure.

**DO NOT** put water directly on the alternator. Entry of water into the alternator can cause corrosion and damage the alternator.

## WIRING

Inspect the entire generator for bad or worn electrical wiring or connections. If any wiring or connections are exposed (insulation missing) replace wiring immediately.

## PIPING AND HOSE CONNECTIONS

Inspect all piping, oil hose, and fuel hose connections for wear and tightness. Tighten all hose clamps and check hoses for leaks.

If any fuel or oil hose lines are defective, replace them immediately.

# GENERATOR START-UP PROCEDURE (MANUAL)

## BEFORE STARTING


### CAUTION

The engine's exhaust contains harmful emissions. **ALWAYS** have adequate ventilation when operating. Direct exhaust away from nearby personnel.

### WARNING

**NEVER** manually start the engine with the **main, GFCI, or auxiliary** circuit breakers in the **ON** (closed) position.

1. Place the **main, auxiliary, and GFCI** circuit breakers (Figure 44) in the **OFF** position prior to starting the engine.



**Figure 44. Main, Auxiliary, And GFCI Circuit Breakers (OFF)**

2. Make sure the voltage change-over board has been configured for the desired output voltage.

### NOTICE


Make sure the tie bolts securing the voltage change-over board bus bars are **secure** and **tight**. The possibility exists of arcing that could cause a fire. Torque bolts to 65.0 lbf·in (14.7 N·m).

3. Connect the load to the **receptacles** or the **output terminal lugs** as shown in Figure 14. These load connection points can be found on the output terminal panel and the output terminal panel's hard wire hookup panel.

### NOTICE

**ALWAYS** make sure that the connections to the UVWO terminals are **secure** and **tight**. The possibility exists of arcing that could cause a fire. Torque tie bolts to 554.9 lbf·in (62.7 N·m).


4. Close all engine enclosure doors (Figure 45).



**Figure 45. Engine Enclosure Doors**

## STARTING (MANUAL)

1. To start the engine, place the **Auto Start/Stop Switch** in the **MANUAL** position (Figure 46).



**Figure 46. Auto Start/Stop Switch (Manual Position)**

### NOTICE

If the engine fails to start within three attempts, the Shutdown lamp will illuminate and the Auto Start/Stop switch must be placed in the Off/Reset position before the next attempt.

### NOTICE

The engine will pre-heat automatically in cold weather conditions. "Glow Plug Hold" message will be displayed and the engine will start automatically after pre-heating.

2. Once the engine starts, let the engine run for 1–2 minutes to warm up. For operation in below-freezing weather temperatures, this warmup period must be extended to 5–7 minutes. During the warmup period, check for any abnormal noise, vibration, or fluid leakage. Check the gauges on the control panel. If any abnormalities exist, shut down the engine and correct the problem.



# GENERATOR START-UP PROCEDURE (MANUAL)

3. The generator's frequency meter (Figure 47) should be displaying the 60-cycle output frequency in **HERTZ**.




Figure 47. Frequency Meter

4. The generator's AC voltmeter (Figure 48) will display the generator's output in **VOLTS**.




Figure 48. Voltmeter

5. If the voltage is not within the specified tolerance, use the voltage regulator (Figure 49) to increase or decrease the desired voltage.




Figure 49. Voltage Regulator

6. The ammeter (Figure 50) will indicate **zero amps** with no load applied. When a load is applied, the ammeter will indicate the amount of current that the load is drawing from the generator.




Figure 50. Ammeter (No Load)

7. The engine oil pressure gauge (Figure 51) will indicate the oil pressure of the engine. Under normal operating conditions the oil pressure should be approximately 44 psi (300 kPa). When starting the generator the oil pressure may read a little higher, but after the engine warms up the oil pressure should return to the normal pressure range.




Figure 51. Oil Pressure Gauge

8. The coolant temperature gauge (Figure 52) will indicate the coolant temperature. Under normal operating conditions the coolant temperature should be between 185°–207°F (85°–97°C).




Figure 52. Coolant Temperature Gauge

9. The tachometer (Figure 53) will indicate the speed of the engine when the generator is operating. Under normal operating conditions this speed is approximately 1,800 rpm.





Figure 53. Engine Tachometer

# GENERATOR START-UP PROCEDURE (MANUAL)


---

10. Place the **main, auxiliary, and GFCI** circuit breakers in the **ON** position (Figure 54).



**Figure 54. Main, Auxiliary, And GFCI Circuit Breakers (ON)**

11. Observe the generator's ammeter (Figure 55) and verify it reads the anticipated amount of current with respect to the load. The ammeter will only display a current reading if a load is in use.



**Figure 55. Ammeter (Load)**

12. The generator will run until manually stopped or an abnormal condition occurs.

# GENERATOR START-UP PROCEDURE (AUTO MODE)

## STARTING (AUTO MODE)

### DANGER



Before connecting this generator to any building's electrical system, a **licensed electrician** must install an **isolation (transfer) switch**. Serious damage to the building's electrical system may occur without this transfer switch.

### WARNING

When operating the generator in **AUTO** mode, remember that the generator can start up at any time without warning. **NEVER** attempt to perform any maintenance while the generator is in Auto mode.

### NOTICE

When the generator is set to **AUTO** mode, the generator will **automatically start** in the event of commercial power falling below a prescribed level by means of a contact closure that is generated automatically by a transfer switch.

### NOTICE

When the **Auto Start/Stop switch** is placed in the **AUTO** position, the engine glow plugs will be warmed and the engine will start automatically.

### NOTICE

When connecting the generator to an isolation (transfer) switch, **ALWAYS** have power applied to the generator's internal battery charger. This will ensure that the engine will not fail due to a dead battery.

### NOTICE

The battery charger option can only be operated when the generator is in Manual Start mode.

1. Perform steps 1–4 under **Before Starting** in the **Generator Start-Up Procedure (Manual)** section.
2. Place the **Auto Start/Stop switch** (Figure 56) in the **AUTO** position.



**Figure 56. Auto Start/Stop Switch (Auto Position)**

3. Once the start signal is received (the remote-start contacts are closed), the pre-heating process will begin. When the pre-heating process has completed, the engine will start automatically and accelerate to rated speed. When the remote-start contacts are opened, the engine will stop.
4. If the engine fails to start, perform the manual starting procedure.

### NOTICE

If the unit has **PowerBalance®** installed, once the main breaker is closed, the PowerBalance® should activate after 1 minute if the load is below 30% of the rated load.

If at any time the load spikes to 90% or more, the PowerBalance® will immediately drop out and wait 5 minutes to re-evaluate the load.

# GENERATOR SHUTDOWN PROCEDURE


## NORMAL SHUTDOWN PROCEDURE

### WARNING

**NEVER** stop the engine suddenly except in an emergency.


To shut down the generator, use the following procedure:

1. Place the load's ON/OFF switch in the **OFF** position.
2. Place the **main, auxiliary, and GFCI** circuit breakers (Figure 57) in the **OFF** position.



**Figure 57. Main, Auxiliary, And GFCI Circuit Breakers (OFF)**

3. Let the engine cool by running it at low speed for 3–5 minutes with no load applied.
4. Place the **Auto Start/Stop switch** (Figure 58) in the **OFF/RESET** position.



**Figure 58. Auto Start/Stop Switch (Off/Reset Position)**

### NOTICE

**DO NOT** disconnect the battery cables immediately after the engine stops. Wait for at least 30 seconds before disconnecting the battery cables.


5. Allow adequate time for cooling, then inspect the entire generator for any damage or loosening of components that may have occurred during operation.

## EMERGENCY SHUTDOWN PROCEDURE

### NOTICE

The **Emergency Stop switch** should **only** be used to stop the engine in case of an emergency or to lock out operation during service. **NEVER** use the Emergency Stop switch for routine stopping of the engine.

1. To stop the engine in the event of an emergency, press the **Emergency Stop switch** (Figure 59).



**Figure 59. Emergency Stop Switch**

2. Place the **main, auxiliary, and GFCI circuit breakers** in the **OFF** position as shown in Figure 57.
3. The Emergency Stop switch is a push-locked type switch. The switch contact can only be released by rotating the button in the clockwise direction. The engine cannot be restarted until the contact is released (closed).

## AUTOMATIC SHUTDOWN SYSTEM

This unit is equipped with safety devices that will automatically shut down the engine when any of the following faults occur:

- High water level in fuel filter separator bowl
- Low oil pressure
- High engine coolant temperature
- High engine fuel temperature
- High charged air cooler outlet temperature
- Severe DPF/SCR system malfunction

The Shutdown lamp on the controller will illuminate and diagnostic trouble codes will be displayed to signify the reason for the shutdown. Refer to the **Troubleshooting** section of this manual for more information.

### NOTICE

Before inspecting the generator after an automatic shutdown, place the Auto Start/Stop switch in the **OFF/RESET** position and place all circuit breakers in the **OFF** position. Allow adequate time for cooling before troubleshooting. When all faults have been cleared, restart the engine according to the **Generator Startup Procedure** section of this manual.

Table 13. Inspection/Maintenance		10 Hours or Daily	250 Hours	Every 500 Hours or 12 Months	Every 3,000 Hours or 36 Months	Other
Engine	Check Engine Oil and Coolant Levels	X				
	Check Fuel Filter/Water Separator Bowl	X				
	Check Air Cleaner	X				
	Check Air Cleaner Element	X				
	Check for Leaks/Hoses/Clamps	X				
	Check for Loosening of Parts	X				
	Change Engine Oil and Oil Filter * <sup>1</sup>		X			
	Clean Unit, Inside and Outside		X			
	Replace Fuel Filter Elements			X		
	Check Engine Mounts			X		
	Service Battery			X		
	Check Air Intake Hoses			X		
	Check Fan Belt Condition			X		
	Check Automatic Belt Tensioner			X		
	Check Electrical Ground Connection			X		
	Clean Radiator, Check Cooling System			X		
	Coolant Solution Analysis, Add SCAs as Required			X		
	Pressure Test Cooling System			X		
	Check Engine Speed			X		
	Test Thermostats				X	
	Check and Adjust Engine Valve Clearance				X	
	Test Glow Plugs				X	
	Inspect Diesel Particulate Filter (DPF) * <sup>2</sup>				X	
	Flush and Refill Cooling System * <sup>3</sup>					2 years or 2,000 hours
	Clean Inside of Fuel Tank					1,000 hours
	Clean DEF Tank					As Required
	Check Crankcase Ventilation Filter * <sup>4</sup>					1,500 hours
	Replace Air Cleaner Elements * <sup>5</sup>					As Required
Generator	Measure Insulation Resistance Over 3M Ohms		X			
	Check Rotor Rear Support Bearing			X		
	Inspect Voltage Change-Over Board Bus Bars and Tie Bolts and Re-Torque Tie Bolts * <sup>6</sup>			X		

\*<sup>1</sup> During initial operation of a new engine, change oil and filter between a minimum of 100 hours and a maximum of 500 hours. Service interval depends on type of engine oil.

\*<sup>2</sup> Expectation for minimum service interval will be at least 4,500 hours based on engine power. However, actual service should take place when indicated by diagnostic gauge. Please contact nearest authorized MultiQuip Service Center for DPF cleaning.

\*<sup>3</sup> If John Deere COOL-GARD is used, the flushing intervals may be extended. See "Testing Diesel Coolant" in the engine manual.

\*<sup>4</sup> Minimal service interval will be at least 1,500 hours or when service indicator light turns on or as indicated by diagnostic gauge. Critical emissions-related service required before 1,500 hours is not necessary. The emissions-related warranty is valid up to 1,500 hours.

\*<sup>5</sup> Replace primary air filter element when restriction indicator shows a vacuum of 625 mm (25 in. H<sub>2</sub>O).

\*<sup>6</sup> Torque bolts to 65.0 lbf-in (14.7 N-m).

## GENERAL INSPECTION


Prior to each use, the generator should be cleaned and inspected for deficiencies. Check for loose, missing or damaged nuts, bolts or other fasteners. Also check for fuel, oil, and coolant leaks. Use Table 13 as a general maintenance guideline. For more detailed engine maintenance instructions, refer to the engine owner's manual.

## ENGINE AIR CLEANER

This John Deere diesel engine is equipped with a replaceable, high-density, paper air cleaner element (Figure 60). The air cleaner is also equipped with an inner (secondary) element that is used as a backup filter should the primary element become damaged. Check the air cleaner daily or before starting the engine. Replace the air cleaner as needed.

### NOTICE

If the engine is operating in very dusty or dry grass conditions, a clogged air cleaner will result. This can lead to a loss of power, excessive carbon buildup in the combustion chamber, and high fuel consumption. Change the air cleaner more frequently if these conditions exist.



**Figure 60. Engine Air Cleaner**

## Primary And Secondary Air Cleaner Elements

**Every 250 hours:** Remove the air cleaner elements and clean them with a light spray of compressed air.

### CAUTION



Wear protective equipment such as approved safety glasses or face shields and dust masks or respirators when cleaning air filters with compressed air.

1. Release the **latches** that secure the **air cleaner cover** to the **air cleaner body** (Figure 60).
2. Remove the air cleaner cover (Figure 60) and set it aside.
3. Remove both the primary and secondary **air cleaner elements** (Figure 60).
4. Check for and correct heavy buildup of dirt and debris along with loose or damaged components.

### NOTICE

Operating the engine with loose or damaged air cleaner components could allow unfiltered air into the engine causing premature wear and failure.

5. To clean the **primary element** (paper air filter) as shown in Figure 60, tap the filter element several times on a hard surface to remove dirt, or blow compressed air, not to exceed 30 psi (207 kPa, 2.1 kgf/cm<sup>2</sup>), through the filter element from the inside out.
6. Clean the **secondary element** (paper air filter) as described in step 5.
7. Replace both elements if they are damaged or excessively dirty.
8. Clean the inside of the air cleaner body (Figure 60).
9. Reinstall the primary and secondary air filter elements back into the air cleaner body.
10. Reinstall the air cleaner cover and secure with the latches.


### NOTICE

**DO NOT** run the engine with the air cleaner removed or without an element.

## Air Cleaner Restriction Indicator

The air cleaner is equipped with a **restriction indicator** (Figure 61). As the air cleaner element becomes clogged, air intake restriction increases and the indicator signal shows **RED**, indicating that the element needs to be replaced. After replacing the air cleaner element, press the restriction indicator button to reset the indicator.

PUSH BUTTON TO RESET



**Figure 61. Air Cleaner Restriction Indicator**

### NOTICE


The air cleaner element should not be changed until the indicator displays **RED**. Dispose of the old element. It cannot be cleaned or reused.

## ENGINE FUEL FILTER

Inspect the engine fuel filter daily. If the fuel filter has collected a significant amount of water and sediment at the bottom of the cup, it should be drained off immediately.

### Draining The Fuel Filter

1. Loosen the air bleeder plug (Figure 62) on the fuel filter head.
2. To discharge the fuel inside the fuel filter cartridge, **OPEN** the drain valve on the fuel filter by turning the knob **counterclockwise** (Figure 62A) approximately 3-1/2 turns until the valve drops down 1 inch (25.4 mm) and draining occurs (Figure 62B).




**Figure 62. Draining The Fuel Filter**

3. Let the residue or foreign substances inside the cartridge flow into a suitable container.
4. At completion of draining, **CLOSE** the drain valve (Figure 62C).



## Fuel Filter Cartridge Replacement

1. Use a filter wrench to remove the fuel filter cup (Figure 63) from the fuel filter head.




**Figure 63. Fuel Filter Cartridge Replacement**

2. Wipe the inside of the filter head with a clean cloth to remove any foreign matter or debris that may have accumulated.
3. Replace both gaskets. Coat each gasket with a small amount of clean 15W-40 engine oil.
4. Install the new fuel filter cartridge first by hand until it makes contact with the fuel filter body surface.
5. Tighten the fuel filter cartridge securely. **DO NOT** overtighten.
6. Remove the air from the fuel system. Reference the John Deere Owner's Manual, "Bleeding the Fuel System."

## Fuel Water Separator Sediment Bowl

1. Remove the sediment bowl from the fuel water separator cartridge as shown in Figure 64.




**Figure 64. Sediment Bowl**

2. Let the residue or foreign substances inside the sediment bowl flow into a suitable container.
3. Wipe the inside of the sediment bowl with a clean cloth to remove any foreign matter or debris that may have accumulated.
4. Reinstall the sediment bowl back onto the fuel water separator cartridge.
5. Tighten securely. **DO NOT** overtighten.

## Fuel Water Separator Replacement

1. Use a filter wrench to remove the fuel water separator cartridge (Figure 65) from the cartridge head.



**Figure 65. Fuel Water Separator**

2. Wipe the inside of the cartridge head with a clean cloth to remove any foreign matter or debris that may have accumulated.
3. Install the new fuel water separator cartridge first by hand until it makes contact with the cartridge head surface.
4. Tighten the fuel water cartridge securely. **DO NOT** overtighten.


## REMOVING WATER FROM THE FUEL TANK

After prolonged use, water and other impurities accumulate in the bottom of the tank. Occasionally inspect the fuel tank for water contamination and drain the contents if required.

During cold weather, the more empty volume inside the tank, the easier it is for water to condense. This can be reduced by keeping the tank full with diesel fuel.

## CLEANING INSIDE THE FUEL TANK

If necessary, drain the fuel inside the fuel tank completely. Using a spray washer (Figure 66) wash out any deposits or debris that have accumulated inside the fuel tank.



**Figure 66. Cleaning The Fuel Tank**


## FUEL TANK INSPECTION

In addition to cleaning the fuel tank, the following components should be inspected for wear:

- **Rubber Suspension** — Look for signs of wear or deformity due to contact with oil. Replace the rubber suspension if necessary.
- **Fuel Hoses** — Inspect nylon and rubber hoses for signs of wear, deterioration or hardening.
- **Fuel Tank Lining** — Inspect the fuel tank lining for signs of excessive amounts of oil or other foreign matter.

## DRAINING THE ENGINE OIL

1. Run the engine until the engine coolant reaches a temperature of 140°F (60°C).
2. Turn the engine off.
3. Remove the oil dipstick from its holder.
4. Remove the **oil drain cap** (Figure 67).
5. Place the **oil drain valve** in the **OPEN** position and allow the oil to drain into a suitable container.



**Figure 67. Draining The Engine Oil**


6. After the engine oil has been completely drained, reinstall the oil drain cap and tighten securely.
7. Place the **oil drain valve** in the **CLOSED** position.

## ENGINE OIL FILTER REPLACEMENT

### NOTICE

Filter head appearance may vary.

1. Using an oil filter wrench (Figure 68), remove the engine oil filter.



**Figure 68. Engine Oil Filter Removal**

2. Clean the area around the lubricating oil filter head.
3. Coat the rubber seal (gasket) surface of the new oil filter (Figure 68) with clean 15W-40 engine oil.
4. Install the new oil filter first by hand until it makes contact with the filter head surface. Tighten it another 3/4 turn using the filter wrench.
5. Fill the engine crankcase with high-quality detergent oil classified "For Service CI-4." Fill to the upper limit of the dipstick. **DO NOT** overfill. Reference Table 2 for engine crankcase oil capacity.
6. Run the engine for several minutes. Watch for oil leakage. Shut the engine down and allow it to sit for several minutes. Top off the oil to the upper limit on the dipstick.

## DRAINING THE ENGINE COOLANT


### ! WARNING



**DO NOT** remove the pressure cap from the radiator when the engine is hot! Wait until the coolant temperature is below 120°F (50°C) before removing the pressure cap.


Heated coolant spray or steam can cause severe scalding and personal injury.

1. Remove the radiator pressure cap (Figure 69) only if the coolant temperature is below 120°F (50°C).



**Figure 69. Radiator Pressure Cap Removal**

2. Open the cabinet door and place the **coolant drain valve** in the **OPEN** position (Figure 70) and allow the coolant to drain into a suitable container.



**Figure 70. Draining The Engine Coolant**

## FLUSHING OUT THE RADIATOR AND REPLACING COOLANT

### ! WARNING



Allow the engine to **cool** before flushing out the radiator. Flushing the radiator while hot could cause serious burns from water or steam.

- Open both cocks located at the crankcase side and at the lower part of the radiator and drain the coolant. Open the radiator cap while draining. Remove the overflow tank and drain.
- Check hoses for softening and kinks. Check clamps for signs of leakage.
- Tighten both cocks and replace the overflow tank.
- Replace with coolant as recommended by the engine manufacturer.
- Close the radiator cap tightly.
- Flush the radiator by running clean tap water through the radiator until signs of rust and dirt are removed. **DO NOT** clean the radiator core with any objects, such as a screwdriver.

## RADIATOR CLEANING

The radiator (Figure 71) should be sprayed clean with a high-pressure washer when excessive amounts of dirt and debris have accumulated on the cooling fins or tube. When using a high-pressure washer, stand at least 5 feet (1.5 meters) away from the radiator to prevent damage to the fins and tube.

### NOTICE

It may be necessary to remove additional generator components in order to access the radiator for cleaning.




Figure 71. Cleaning The Radiator

## DRIVE BELT INSPECTION

Inspect the drive belt (Figure 72) for damage and wear. Horizontal cracks (across the belt) are acceptable. Vertical (direction of belt ribs) cracks that intersect with horizontal cracks are not acceptable.




Figure 72. Drive Belt Inspection

Also, examine the belt and determine if it is **oil soaked** or **glazed** (a hard shiny appearance on the sides of the belt). Either of these two conditions can cause the belt to run hot, which can weaken it and increase the danger of it breaking.


If the drive belt exhibits any of the above wear conditions, replace the drive belt immediately.

## TESTING THE GFCI RECEPTACLE

### NOTICE


The GFCI receptacle is designed to interrupt power when a ground fault exists to prevent injuries and shock hazards. **DO NOT** use the GFCI receptacle if the test below fails. Consult a qualified electrician for repair or replacement of the GFCI receptacle. Test the GFCI receptacle **at least once a month**.

1. Start the generator as outlined in the start-up procedure in this manual.
2. Place a GFCI circuit breaker (Figure 73) in the **ON** position.




**Figure 73. GFCI Circuit Breaker**

3. Verify that the status LED on the corresponding GFCI receptacle (Figure 74) is **ON (GREEN)**.




**Figure 74. GFCI Receptacle (ON)**

4. Press the **TEST** button (Figure 75) on the GFCI receptacle and verify that the status LED turns **OFF**.




**Figure 75. GFCI Receptacle (OFF)**

5. Press the **RESET** button (Figure 76) to restore power to the GFCI receptacle and verify that the status LED is **ON (GREEN)**.



**Figure 76. GFCI Receptacle (ON/Restore)**

6. If the status LED (Figure 77) is **flashing (RED)**, **DO NOT** use the GFCI receptacle and replace it immediately.



**Figure 77. GFCI Receptacle (RED Flashing LED)**

7. Repeat the above procedure for the other GFCI receptacle.

## GENERATOR STORAGE

For long-term storage of the generator the following is recommended:

- Drain the fuel tank completely. Treat with a fuel stabilizer if necessary.
- Completely drain the oil from the crankcase and refill if necessary with fresh oil.
- Clean the entire generator, internal and external.
- Cover the generator and store it in a clean, dry place.
- Disconnect the battery.
- Make sure engine coolant is at the proper level.
- If the generator is mounted on a trailer, jack the trailer up and place it on blocks so the tires do not touch the ground or block and completely remove the tires.

## OPTIONAL ENGINE BLOCK HEATER AND INTERNAL BATTERY CHARGER 120 VAC INPUT RECEPTACLES

An **engine block heater** and an **internal battery charger** are available as **options**. They are provided with electrical cords to connect to a commercial power source.

The engine block heater and internal battery charger (Figure 78) both require 120 VAC in order to operate. Two power receptacles are provided on the output terminal panel to allow commercial power to be applied.

These units will **ONLY** function when commercial power has been supplied to them. When using extension cords, refer to Table 7 for the correct size and length.

When using the generator in hot climates there is no reason to apply power to the engine block heater. However, if the generator will be used in cold climates it is always a good idea to apply power to the heater at all times.

If the generator will be used daily, the battery should normally not require charging. If the generator will be idle (not used) for long periods of time, apply power to the battery charger receptacle via commercial power using a power cord of adequate size.

### NOTICE

If the generator will be idle (not used) for long periods of time, **ALWAYS** keep power supplied to the generator's internal battery charger to ensure adequate starting capability.





Figure 78. Engine Block Heater And Battery Charger (Options)



## EMISSION CONTROL

The emission control system employed with the John Deere 6068HFG09 diesel engine consists of a Diesel Oxidation Catalyst (DOC) and a Diesel Particulate Filter (DPF). The oxidation catalyst and particulate filter are housed within one unit (Figure 79).



**Figure 79. Typical DOC/DPF Unit**

These devices help filter out large amounts of harmful Nitrogen Oxides (NO<sub>x</sub>) and Particulate Matter (PM) which are emitted by diesel engines. These exhaust emissions pose serious environmental and health risks. It is important to maintain and service this DOC/DPF emission safety device on a periodic basis.

### Diesel Oxidation Catalyst (DOC)

The DOC does not filter particles, it oxidizes them. This catalyst (honeycomb-like structure) uses a chemical process to break down pollutants in the exhaust stream into less harmful components. In general, this catalyst collects and burns accumulated particulates. The DOC contains palladium and platinum which serve as catalysts to oxidize hydrocarbons and carbon monoxide.

### Diesel Particulate Filter (DPF)

A diesel particulate filter (DPF) is a device designed to remove diesel particulate matter (soot) from the exhaust of a diesel engine. This type of filter usually removes about 85–95% of the soot.

## REGENERATION

Soot accumulated in the DPF is removed via the **regeneration** process. Regeneration is the process of removing the accumulated soot from the filter. This process can occur in a few different ways:

■ **Passive Regeneration** — Occurs during normal operation, typically under heavy load applications. Soot is oxidized faster than it is collected.

■ **Active Regeneration** — Occurs when engine exhaust temperatures are not high enough to oxidize the soot collected in the DPF. Active regeneration requires assistance from the engine to help increase the heat level in the after-treatment system.

Active regeneration occurs at a normal engine speed of 1,800 rpm, and is initiated automatically by the Engine Control Module (ECM) timer-based program every 96 hours. This timer-based program will reset at the end of any regeneration mode.

■ **Forced (Stationary) Regeneration** — A forced regeneration only occurs when the operator has initiated this action at the ECU and the ECM recognizes a preprogrammed set point of soot in the DPF to allow a forced regeneration cycle.

This process can take anywhere from 30 minutes to 1½ hours. When forced regeneration is in progress, all loads must be removed from the generator, all circuit breakers must be placed in the OFF (OPEN) position, and the engine speed set to idle.

## Regeneration Guidelines

For the safe operation of equipment, protection of the surrounding area, and prevention of bodily harm, use the guidelines below when regeneration is required:

- **DO NOT** perform regeneration in conditions where it may be unsafe due to high exhaust temperatures.
- **DO NOT** operate the unit in an area with poor ventilation.
- If operating the engine indoors, install exhaust/ventilation equipment and ensure that there is sufficient ventilation.
- If you begin to feel sick, stop the unit immediately and ventilate the area.
- During the regeneration process, the area above and around the generator should be free of any type of debris or flammable/combustible materials, as temperatures during the regeneration process can reach as high as 1,022°F (550°C).

## NOTICE


During system regeneration, **white smoke** may be temporarily emitted from the exhaust tailpipe. This should not be considered a failure. In addition, the smell of **ammonia** during the regeneration process should not be considered a failure.

If the regeneration process is underway while running a light load (0–30%), the unit may produce unusual sounds. This also should not be considered a failure or malfunction.

## DPF PRE-ALARM

When the Engine Control Unit (ECU) determines that the soot level back pressure and/or temperature has reached a pre-determined trip point, the ECU will indicate a maintenance action is required by the operator.

This maintenance action will be shown on the LCD display (DPF Warning Icon) and the AMBER pre-alarm LED on the ECU control panel will be ON (lit). See Figure 80.




**Figure 80. ECU DPF Pre-Alarm**

The DPF pre-alarm status icon displayed in Figure 80 indicates the soot level buildup has exceeded a predetermined level and a **forced regeneration** action is required.

## NOTICE

When the **AMBER** pre-alarm warning LED turns **ON (lit)**, the operator should **ALWAYS** take **immediate action** to correct the problem. If the engine is allowed to continue running during this condition, a higher pressure differential will be created in the DPF, resulting in an **engine shutdown** and the **RED** status LED turning **ON**.



**Figure 81. ECU DPF Engine Shutdown**

## NOTICE

If the **RED** engine shutdown LED turns **ON** (Figure 81), John Deere recommends that the DPF be removed, cleaned or replaced, and the shutdown code must be cleared. To clear the code, the ECM must be reset by a licensed John Deere Engine Service Technician, using John Deere service software.

## NOTICE

Soot and ash will accumulate in the DPF over time and must be cleaned. The ash is a result of normal oil consumption during engine operation. The ash cleaning interval largely depends on the engine's duty cycle and condition. Normal service interval for cleaning ash from the DPF is every 6 months (5,000 hours).

## FORCED REGENERATION PROCEDURE

Follow the steps below to initiate a forced regeneration.

1. Verify the **AMBER** pre-alarm LED is **ON** or **FLASHING** and the DPF icon is shown on the ECU display.
2. Place all circuit breakers in the **OFF** position.
3. Press the **Program/Exit** button on the ECU controller and select **FORCE REGEN** mode.
4. Press and hold the request until the **REGEN ACTIVE** message is displayed on the screen, then release.
5. Once activated, regeneration will start automatically and engine speed will increase through the forced regeneration cycle. This process will last anywhere from 30 minutes to 1½ hours.

### NOTICE

During the regeneration cycle, the High Exhaust System Temperature (**HEST**) icon may be displayed. Display of this icon can be considered normal during the regeneration period.



## AUTO REGENERATION PROCEDURE

The auto regeneration process will occur automatically. No operator action is required. Allow the engine to run for at least 30 minutes to complete the auto regeneration process.

Refer to Table 14 for the various soot level stages of the DPF system.





### NOTICE

Generator derating occurs during soot levels 4 and 5. Soot level 5 will cause the generator to shut down. If this condition occurs, contact your nearest authorized service center.

## REGENERATION (OPTIONAL BASLER DGC-2020HD CONTROLLER)

If a manual regeneration is needed, the Basler DGC-2020HD controller will announce a pre-alarm which states “**NEED MAN REGEN**” and “**PRESS RUN BUTTON**”. During this condition, press the RUN button for 5 seconds to initiate the Stationary Forced Regen. The controller will then display a new pre-alarm “**MAN REGEN ACTIVE**”. Once the regen completes, it will automatically shut down and display “**MAN REGEN COMPLT**”.


Table 14. Automatic DPF System

	Soot Level 0	Soot Level 1 & 2	Soot Level 3	Soot Level 4	Soot Level 5
<b>Controller Message</b>	N/A	N/A	FILTER CLEAN REQUESTED	SOOT LEVEL HIGH!	SOOT LEVEL VERY HIGH!
<b>DPF Condition</b>	Regen Not Required	Moderate Soot Level	High Soot Level	Very High Soot Level	Service DPF (Soot Only)
<b>Pre-Alarm Lamp</b>	N/A	N/A	 Blinking	 ON	 ON
<b>Shutdown Lamp</b>	N/A	N/A	N/A	N/A	 ON Engine Shutdown

## DIESEL EXHAUST FLUID (DEF)


If the **diesel exhaust fluid** (DEF) icon (Figure 82) is displayed during ECU controller operation, it indicates one or more of the following:

- DEF tank level is below 10%. Refer to Table 15, DEF Level System Action.
- DEF quality is poor. Check DEF tank level and check active **diagnostic trouble codes** (DTC).



**Figure 82. ECU DEF State Pre-Alarm**

The amount of fluid in the DEF tank will be shown on the ECU controller main screen during operation. The icon shown in Figure 83 will be shown on the ECU monitor indicating the level of fluid in the DEF tank.



**Figure 83. DEF Tank Level Gauge**

## DEF SEVERE INDUCEMENT ALARMS (OPTIONAL BASLER DGC-2020HD CONTROLLER)

If a warning for DEF Severe Inducement is present, consider it just like a “Check Engine Light”. The reason for the inducement alarm is available under the menu: Metering->J1939-> Active DTC.

### DEF Severe Inducement PA (PA = Pre-Alarm):

This is a notice to the operator to correct the issue before it escalates to an alarm. Pre-alarm is commonly active when the DEF tank is at a low level. If the DEF tank is refilled, the Pre-Alarm is cleared and the unit suffers no adverse effects.

### DEF Severe Inducement A (A = Alarm):

This is a notice to the operator that an after-treatment related DTC is causing the unit to enforce 70% de-rated power and the unit will not be allowed to carry full load. If the load is higher than 30% more than likely the control panel will show an “Under Frequency” (81) warning or alarm.

#### NOTICE

Unit derate occurs at 0% DEF level. If the DEF level is at empty, the engine will shut down. When replenishing diesel fuel, **ALWAYS** refill the DEF tank as well.

#### NOTICE

Generator derating occurs during soot levels 4 and 5. Soot level 5 will cause the generator to shut down. If this condition occurs, contact your nearest authorized service center.


**Table 15. DEF Level System Action**

DEF Level	Over 10%	Below 10%	0%	Empty or After 4 Hours From 0%
Controller Message	—	DEF<10% Tank Level	DEF<10% Tank Level	DEF Tank Empty Level
DEF Icon	—	● ON	● Blinking	● Blinking
Pre-Alarm Lamp	—	—	● ON	● ON
Shutdown Lamp	—	—	—	● ON Engine Shutdown

## ENGINE EMISSIONS SYSTEM MALFUNCTION

If the **engine emissions system malfunction** (EESM) icon (Figure 84) is displayed during ECU controller operation, it indicates the following:

- Engine emissions are outside of the normal operation range.
- A system fault has occurred. Refer to the **Troubleshooting** section.



**Figure 84. Engine Emissions System Malfunction Pre-Alarm**

## TROUBLESHOOTING (DIAGNOSTICS)

The engine controller of this generator diagnoses problems that arise from the engine control system and the engine itself.

1. With the engine stopped (**OFF**), press and hold the **Hour Check button** (Figure 85) located on the control panel.




Figure 85. Hour Check Button

2. While keeping the **Hour Check button** pressed, place the **Auto Start/Stop switch** (Figure 86) in the **MANUAL** position.




Figure 86. Auto Start/Stop Switch (Manual Position)

3. The **Hour Check Menu screen** will be displayed on the ECU controller.
4. Release the **Hour Check button** and press the **Program/Exit button** on the ECU controller to return to the main screen.

5. Press the **Program/Exit button** on the ECU controller and select **Fault Diagnostics** mode. This mode enables the ability to carry out the fault diagnostics as listed below:

■ **DM1 Active Faults** — Displays active fault messages and codes.

■ **DM2 Messages and Codes** — Displays messages and codes which previously occurred that are recorded in the Engine Control Module (ECM).

■ **Last Shutdown** — Displays the messages and codes that caused the most recent shutdown.

6. After performing diagnostic tests, place the **Auto Start/Stop switch** in the **OFF** position.

### DIAGNOSTIC MODE (OPTIONAL BASLER DGC-2020HD CONTROLLER)

The optional DGC-2020HD controller can be placed in Diagnostic mode, which will keep the key switch on for service tool purposes. To place the unit in Diagnostic mode, the engine must be turned **OFF**.

1. Press the Alarm Silence button and the Lamp Test button simultaneously for 5 seconds.

#### NOTICE

When Diagnostic mode is enabled, the message “**DIAG MODE ACTIVE Pre-Alarm**” will be displayed on the Pre-Alarm screen.

2. Use the Arrow buttons to navigate to the J1939 ECU menu (Metering->J1939 ECU). This will allow the operator to perform the following diagnostics:

■ **DTC Active Data** — Displays active fault messages and codes.

■ **DTC Previous Data** — Displays messages and codes which previously occurred that are recorded in the engine control module (ECM).

3. To exit Diagnostic mode, press the Reset button, start the engine, or turn control power off.

## TROUBLESHOOTING (GENERATOR)

Practically all breakdowns can be prevented by proper handling and maintenance inspections, but in the event of a breakdown, use Table 16 for diagnosis of the generator. If the problem cannot be remedied, contact the Multiquip Technical Support Department.

Table 16. Generator Troubleshooting		
Symptom	Possible Problem	Solution
No Voltage Output	Defective AC voltmeter?	Check output voltage and replace if necessary.
	Loose wiring connection?	Check wiring and repair.
	Defective AVR?	Replace if necessary.
	Defective rotating rectifier?	Check and replace.
Low Voltage Output	Incorrect engine speed?	Check and adjust.
	Loose wiring connection?	Check wiring and repair.
	Defective AVR?	Replace if necessary.
High Voltage Output	Loose wiring connection?	Check wiring and repair.
	Defective AVR?	Replace if necessary.
Circuit Breaker Tripped	Short circuit in load?	Check load and repair.
	Over current?	Confirm load requirement and reduce.
	Defective circuit breaker?	Check and replace.
	Overcurrent relay actuated?	Confirm load requirement and reset.



# TROUBLESHOOTING (ENGINE)

Troubleshooting (Engine)		
Symptom	Possible Problem	Solution
Engine will not start or start is delayed, although engine can be turned over.	No fuel reaching injection pump?	Add fuel. Check entire fuel system.
	Defective fuel pump?	Replace fuel pump.
	Fuel filter clogged?	Replace fuel filter and clean tank.
	Faulty fuel supply line?	Replace or repair fuel line.
	Compression too low?	Check piston, cylinder and valves. Adjust or repair per engine repair manual.
	Fuel pump not working correctly?	Repair or replace fuel pump.
	Oil pressure too low?	Check engine oil pressure.
	Low starting temperature limit exceeded?	Comply with cold starting instructions and proper oil viscosity.
	Defective battery?	Charge or replace battery.
	Air or water mixed in fuel system?	Check carefully for loosened fuel line coupling, loose cap nut, etc.
At low temperatures engine will not start.	Engine oil too thick?	Refill engine crankcase with correct type of oil for winter environment.
	Defective battery?	Replace battery.
Engine fires but stops as soon as starter is switched off.	Fuel filter blocked?	Replace fuel filter.
	Fuel supply blocked?	Check the entire fuel system.
	Defective fuel pump?	Replace fuel pump.
Engine stops by itself during normal operation.	Fuel tank empty?	Add fuel.
	Fuel filter blocked?	Replace fuel filter.
	Defective fuel pump?	Replace fuel pump.
	Mechanical oil pressure shutdown sensor stops the engine due to low oil?	Add oil. Replace low oil shutdown sensor if necessary.
Low engine power, output and speed.	Fuel tank empty?	Add fuel.
	Fuel filter clogged?	Replace fuel filter.
	Fuel tank venting is inadequate?	Ensure tank is adequately vented.
	Leaks at pipe unions?	Check threaded pipe unions. Tape and tighten unions as required.
	Speed control lever does not remain in selected position?	See engine manual for corrective action.
	Engine oil level too full?	Correct engine oil level.
	Injection pump wear?	Use No. 2-D diesel fuel only. Check the fuel injection pump element and delivery valve assembly and replace as necessary.


## TROUBLESHOOTING (ENGINE)

Troubleshooting (Engine) - continued		
Symptom	Possible Problem	Solution
Low engine power output and low speed, black exhaust smoke.	Air filter blocked?	Clean or replace air filter.
	Incorrect valve clearances?	Adjust valves per engine specification.
	Malfunction at injector?	See engine manual.
Engine overheats.	Too much oil in engine crankcase?	Drain off engine oil down to upper mark on dipstick.
	Entire cooling air system contaminated or blocked?	Clean cooling air system and cooling fin areas.
	Fan belt broken or elongated?	Change belt or adjust belt tension.
	Coolant insufficient?	Replenish coolant.
	Radiator net or radiator fin clogged with dust?	Clean net or fin carefully.
	Fan, radiator, or radiator cap defective?	Replace defective part.
	Thermostat defective?	Check thermostat and replace if necessary.
	Head gasket defective or water leakage?	Replace parts.

# GENERATOR WIRING DIAGRAM (M4814000103)

MARK	N	A	M	E
Ar				MAIN GENERATOR ARMATURE WINDING
Eg				MAIN GENERATOR FIELD WINDING
ExAr				EXCITER ARMATURE WINDING
ExFg				EXCITER FIELD WINDING
AVR				AUTOMATIC VOLTAGE REGULATOR
VR				VOLTAGE REGULATING RESISTANT
Re				RECTIFIER
CT1-3				CURRENT TRANSFORMER 400-5A
CT4, 5				CURRENT TRANSFORMER 400-5A
CB1				CIRCUIT BREAKER 3P 600A
OC				OVER CURRENT RELAY
COT. B				VOLTAGE CHANGE-OVER BOARD
AS				AMMETER CHANGE-OVER SWITCH
A				AC. AMMETER 0-400. 800A
VS				VOLTMETER CHANGE-OVER SWITCH
V				AC. VOLTMETER 0-600V
F				FREQUENCY METER 45-65Hz
CB2, 3				AUX. CIRCUIT BREAKER 1P 20A
CB4-6				AUX. CIRCUIT BREAKER 2P 50A
CON1, 2				AUX. POWER RECEPTACLE 20A
CON3-5				AUX. POWER RECEPTACLE 50A

CT 4, 5	
Written mark at CT	
k	X1
l	No mark
K	H1
L	No mark




Notice:  
If measure insulation resistance,  
disconnect CN6 and CN9.




GENERATOR WIRING DIAGRAM NO. M4814000103

WIRE SIZE		COLOR CODE	
TYPE	mm <sup>2</sup>	WIRE COLOR	WIRE COLOR
100	100	BLACK	R
60	60	RED	W
32	32	BLUE	Y
22	22	BROWN	LG
14	14	GREEN	O
5.5	5.5	YELLOW	P
2	2	ORANGE	


# GENERATOR WIRING DIAGRAM (BASLER DGC-2020HD OPTION)



SYMBOL	DESIGNATION	SYMBOL	DESIGNATION
Ar	ARMATURE WINDING	COT. B	VOLTAGE CHANGE-OVER BOARD
Fg	MAIN GENERATOR FIELD WINDING	CB2~3	AUX. CIRCUIT BREAKER 1-POLE, 20A
Ex Ar	EXCITER ARMATURE WINDING	CB4~6	AUX. CIRCUIT BREAKER 2-POLE, 50A
Ex Fg	EXCITER FIELD WINDING	CB7~8	CIRCUIT BREAKER 3-POLE, 10A
AVR	AUTOMATIC VOLTAGE REGULATOR	CB9	CIRCUIT BREAKER 2-POLE, 20A
Re	RECTIFIER	K1	CONTACTOR, 240 VAC
CT1~3	CURRENT TRANSFORMER 750/5A	CON2~3	RECEPTACLE 520R GFCI 20A, 125V
CB1	CIRCUIT BREAKER 600 AMPS	CON3~5	RECEPTACLE CS-6369 50A, 120/240V




# ENGINE WIRING DIAGRAM (M5844300204)



ENGINE WIRING DIAGRAM NO. M5844300204

# ENGINE WIRING DIAGRAM S/N 8011013 AND ABOVE (M5814100713)




ENGINE WIRING DIAGRAM NO. M5814100713  
S/N 8011013 AND ABOVE





## BATTERY CHARGER WIRING DIAGRAM (OPTION)




### NOTES:

△1 NEMA 5-15, 15A, 120 VAC (HBL5278C/HUBBLE RECEPTACLE).

△2 RECEPTACLE IS MOUNTED ON OUTPUT TERMINAL PANEL ASSY.

## ENGINE BLOCK HEATER WIRING DIAGRAM (OPTION)



### NOTES:

- ① NEMA 5-15, 15A, 120 VAC (HBL5278C/HUBBLE RECEPTACLE)
- ② RECEPTACLE IS MOUNTED ON OUTPUT TERMINAL PANEL ASSY.
- ③ NEMA L5-20R, 20A, 125 VAC (HBL5369C/HUBBLE RECEPTACLE).
- ④ RECEPTACLE IS MOUNTED ADJACENT TO WATER HEATING ELEMENT.

[illegible]

# OPERATION MANUAL

## HERE'S HOW TO GET HELP

PLEASE HAVE THE MODEL AND SERIAL  
NUMBER ON HAND WHEN CALLING

### UNITED STATES

#### ***Multiquip Inc.***

(310) 537- 3700  
6141 Katella Avenue Suite 200  
Cypress, CA 90630  
E-MAIL: [mq@multiquip.com](mailto:mq@multiquip.com)  
WEBSITE: [www.multiquip.com](http://www.multiquip.com)

---

### CANADA

#### ***Multiquip***

(450) 625-2244  
4110 Industriel Boul.  
Laval, Quebec, Canada H7L 6V3  
E-MAIL: [infocanada@multiquip.com](mailto:infocanada@multiquip.com)

### UNITED KINGDOM

#### ***Multiquip (UK) Limited Head Office***

0161 339 2223  
Unit 2, Northpoint Industrial Estate, Globe Lane,  
Dukinfield, Cheshire SK16 4UJ  
E-MAIL: [sales@multiquip.co.uk](mailto:sales@multiquip.co.uk)

© COPYRIGHT 2025, MULTIQUIP INC.

Multiquip Inc., the MQ logo and the MQ Power logo are registered trademarks of Multiquip Inc. and may not be used, reproduced, or altered without written permission. All other trademarks are the property of their respective owners and used with permission.

This manual MUST accompany the equipment at all times. This manual is considered a permanent part of the equipment and should remain with the unit if resold.

DISCLAIMER: Product features, descriptions, and specifications are based on published information at the time of publication and are subject to change at any time without notice. Multiquip Inc. and its affiliates reserve the right to change specifications, features, design, and descriptions of products at any time without notice.

Manufactured for  
MQ Power Inc.  
by  
DENYO MANUFACTURING CORP.

