



Concrete Mixers Maintenance Instructions

The following instructions are intended to assist the user in maintaining Multiquip Concrete Mixers.

Engine/Mixer Maintenance Schedule									
DESCRIPTION	OPERATION	BEFORE EACH USE	WEEKLY	FIRST MONTH OR 10 HRS.	EVERY 3 MONTHS OR 25 HRS.	EVERY 6 MONTHS OR 50 HRS.	EVERY YEAR OR 100 HRS.	EVERY 16 MONTHS	EVERY 2 YEARS OR 200 HRS.
Engine Oil	CHECK	X							
	CHANGE			X		X			
Air Cleaner	CHECK	X							
	CHANGE				X (1)				
All Nuts & Bolts	Re-tighten if necessary	X							
Spark Plug	CHECK-CLEAN					X			
	REPLACE								X
Cooling Fins	CHECK					X			
Spark Arrester	CLEAN						X		
Idle Speed	CHECK-ADJUST						X (2)		
Valve Clearance	CHECK-ADJUST								X (2)
Fuel Tank	CLEAN						X		
Fuel Filter	CHECK						X		
Fuel lines	CHECK	Every 2 years (replace if necessary) (2)							
Pivot Points & Clamp Face	LUBRICATE (W/ SAE 30 Wt. Motor Oil)	Periodically							
Grease Fittings (Mixer)	LUBRICATE (W/ Lithium-base grease, grade no.1)		X						
Grease Fittings (Electric Motor)	LUBRICATE (W/ Polyrex EM)							X	
Wheel Bearings	CHECK			X					
	CLEAN/LUBRICATE						X		
Tire Pressure	CHECK (COLD)		X						
Suspension	INSPECT	EVERY 6, 000 MILES (signs of excessive wear, elongation of bolt holes, and loose fasteners)							

(1) Service more frequently when used in **DUSTY** areas.

(2) These items should be serviced by your service dealer, unless you have the proper tools and are mechanically proficient. Refer to the HONDA/ROBIN Shop Manual for service procedures.



MULTIQUIP INC.

POST OFFICE BOX 6254 • CARSON, CA 90749
310-537-3700 • 800-421-1244 • FAX: 310-537-3927
E-MAIL: mq@multiquip.com • WWW: multiquip.com
Montreal, Canada • Manchester, UK
Rio De Janeiro, Brazil • Cipsa, Mexico