RX1575 Electric

Tier 4i Engine Spec # 3TVN76-PAAM
Tier 4F Engine Model # 3TNV80F-SPAMM

Notes

*All BROWN wires are always a GROUND circuit.

S1 - Ignition Switch P/N 1-30005179

Term 15 - Ignition
Term 19 - Pre Heat
Term 50 - Starter

Ignition Switch Terminals

Cock Pit fuses

F11 - 10 amp - Machine controller supply
F12 - 25amp - Machine controller outputs
F13 - 10 amp - Display unit, shutdown bar
F14 - 25 amp - Hydraulic cooler

Engine Compartment fuses

F21 - 40 amp - Stop Soleniod
F22 - 10 amp - Fuel Pump, Alt Battery +
F23 - 40 amp - High Speed Solenoid
F24 - 40 amp - Pre Heat
F25 - 40 amp - Single Coil (tier 4 option)

Complete Engine Wiring Harness
P/N 1240161 S/N 5570001 and below
P/N 1299556 S/N 5570002 - 5570382
P/N 4-10786343 W/Beacon S/N 5570383 - 5571999

Filter Numbers

Engine Oil Filter 11930535151
Fuel/Water Sep 17108155910
T4i Air Filter 1224448
T4F Air Filter Outer 1300308
T4F Air Filter Inner 1300309
Fuel Filter 11981055650
Fuel Pump 11922552102
500 Hr Service Kit 1228783

Cannon Plug Connector to N1 - Machine Controller

IR Transmitter Parts

Start/Stop Switch - P/N 52077
High/Low Speed - P/N 52011
Rubber Boots - P/N 1415868
4-Wire Battery - P/N 1266872
Vibration Switch - P/N 52010
Horn - P/N 1449852
Vent - 1430840
Transmitter Board - Not Serviceable

K1 - Main IGN Relay
P/N 1227066
82 Ohm Coil

Plug #	Wire #	Plug #	Wire #
1	180	6	178
2	Not Used	7	139 & 107
3	Not Used	8	130
4	Not Used	9	152 & 106
5	134	10	Not Used

Ignition Switch Terminals, Wires & Position Logic

N2 - Display Unit
P/N 1226581

When Ign ON, pin 7 must have 0V to batt neg and when engine running it must have 12VDC

N2 -Display Unit

P3 - Hour Meter
H1 - Battery Charge indicator
H2 - Pre-heating lamp
H3 - Oil Pressure indicator
H4 - Water Temp indicator
H5 - Shutdown bar warning lamp
H6 - Error warning lamp

N3 - Infrared Transmitter
P/N 1226283

Charge/Pairing Connection (Coil Cord)
Cable P/N 1242589

Input voltage from machine controller Term 3 & 4 = Battery Voltage

IR Sensor
Front IR Sensor
P/N 1226285

X5 is a connector for the front sensor/Ext cable that is located on the left side of the engine base harness area.
P/N 1292241

Input voltage from machine controller Term 3 & 4 = Battery Voltage

IR Sensor
Rear IR Sensor
P/N 1226285

Flashing beacon equipped on S/N 5570383 - 5572000.

IR Beacon
Beacon Light
P/N 1414300

S24 - Reverse Safety Sensor/Loop

Open Reverse bar circuit is indicated on the Display Panel by turning on H5 Lamp.

H3 - Oil Pressure indicator
H4 - Water Temp indicator

All INPUTS run on the top of Machine Controller in diagram expect for voltage to the IR receiving eyes

N1 - Machine Controller

P/N 1226284 (NLA) S/N 5570553 Supersede to P/N 1449282
P/N 1414301 S/N 5570383 - 5571999
It's possible to use P/N 1449282 to replace P/N 1414301 on units w/ sep beacon.
Adapter y-cable P/N 1449286 is require to function beacon.

K2 - Start Relay
P/N 1-493887
20 Ohm Coil

K3 Timer
Meter set to 600K ohm
Red lead = RT
Blk lead = SW
310K Ohms
Reverse leads = 0
Check for VDC at RT-GB.
Don t use Auto-range

K4 - Relay Coil 85-86= 37 ohms Draws .3a

Shaded Area Tier 4F Option

Wire Colors
RT = Red
SW = Black
RTWS = Red/White
GB = Yellow
WS = White

Y1 - Fuel Shutoff Solenoid
P/N 11923377932

S25 - Hydro Oil Temp Switch closes at 122 degrees F

K7 - Hyd Fan Relay
P/N 1227066
82 Ohm Coil

Y3 - Y4 Drive Solenoids
Coil Resistance 6 Ohms

Y5 - Y9 Hydraulic Valve Solenoids
Coil Resistance 6 ohms
Current Draw - 2.5 amp

Horn added after S/N 5570553

K5 - High Speed Solenoid Relay
P/N 1227066
82 Ohm Coil

K6 - Glow Plug Relay
P/N 1227066
82 Ohm Coil

N2 - Display Unit

Y2 - use proper polarity. Must be adjusted properly

R1 - Glow Plugs
Glow Plugs are not on a timer
Amp Draw 10Amps

S22 - Water Temp Switch must be OPEN in Normal temps. 4s Delay

S21 - Oil Pressure switch must be closed when the engine is stopped. Closed when starting & open when running. 4s Delay

Water Temperature P/N 12125044901
Engine Oil Pressure P/N 11425039450

G1 - Alternator

P/N 129423-77200
Term 30 : 14.5V output
Term D+ : Ground out for Display, K2 relay, controller timer.
D+ must have 0V when the Ign is on.
D+ must have 12V when the engine is running
Term 15 : Ignition circuit power from K1 relay.

M1 - Starter Motor

P/N 1-954079
Amps / 250 Peak / 150 Continuous

High Speed Solenoid

P/N 1226545
Amps / 8.9 Peak / .5 Continuous

Hyd Test Pressures @ High Speed

Drive Pressure Relief - 4000psi
Charge Pressure - 300psi
Vibration Pressure - 3000/1500psi
Steering Pressure - 1000psi

* Stauff-Test 20 Adapter (SMS-20/N1/4)

Relay ID and Description

K1 - Main Ignition Relay (P/N 1227066)
K2 - Starter Relay (P/N 1-493837)
K3 - Timer Relay (1s.) (P/N 1-952515)
YM:129211-77920
K4 - Pull-in Stop Solenoid (P/N 1-952514) NGK:G71SU
K5 - High Speed Solenoid Relay (P/N 1227066)
K6 - Glow Plug Relay (P/N 1227066)
K7 - Hydro Cooler Fan Relay (P/N 1227066)
K11 - Solenoid Driver Relay (Tier 4F only)
K1/K7 Spec - 12VDC-40A/15A

Solenoid Valve Descriptions

Approx coil resistance is 6 ohms for Y3,4,5,6,7,8,9
Y1 - Fuel Shutoff Solenoid
Y2 - High Speed Solenoid
Y3 - Drive Forward
Y4 - Drive Reverse
Y5 - Steering Left
Y6 - Steering Right
Y7 - High Amplitude
Y8 - Low Amplitude
Y9 - Brake Valve
Y11 - 2nd Holding Solenoid (Tier 4F only)

Drive Speed Voltage to Coils

High Speed - 4.8 DCV to Coil
Low Speed - 3.6 DCV to Coil
Note: Voltage check must be done with connector plugged in. Unit will read stray voltage if test is not done correctly. Make this test while engine running, back probe connectors.

RX1575 Trench Roller

Infrared Safety Zone : Spec's from manual, actual may vary.
Max range w/ cable 11ft. ~ Max w/ IR 60ft
Min proximity range 8ft

Y2 - High Speed Solenoid P/N 1226545 Adjustment Leave 1.5mm gap.

MQ Service Edits RevB

Diese Zeichnung darf ohne unsere schriftliche Bewilligung weder vervielf., noch physisch/elektr. Dritt/Personen zugegl. oder zugänglich gemacht, noch zur Selbstausführung oder zur Herstellung durch Dritte benutzt werden