



14. GENERATOR WIRING DIAGRAM

SYMBOL	PARTS NAME
A r	Armature Winding
F g	Field Winding
EXW1~2	Excitation Winding
V	AC Voltmeter
Re 1 ~2	Rectifier
CON1	Receptacle (120V/240V, 50A)
CON2	Receptacle (120V/240V, 30A)
CON3	Receptacle (120V, 30A)
CON4	Receptacle (120V, 20A-GFCI)
CB	Circuit Breaker (FOR MAIN-GFCI)
CB 1	Circuit Protector (FOR 120V, 20A)
SW 1	Idle Control Switch
RC	Idle Control Device
S	Solenoid
R y	Relay
R	Resistor



CONNECTOR (Viewed at Winding Side)



Combination terminal

- TB 1 U N N V
TB 2 J K A C 5 0 1 9 3 0

CODE	WIRE COLOR	CODE	WIRE COLOR
B	BLACK	R	RED
L	BLUE	W	WHITE
BR	BROWN	Y	YELLOW
G	GREEN	LB	LIGHT BLUE
GR	GRAY	LG	LIGHT GREEN
V	VIOLET	O	ORANGE
P	PINK		

15. ENGINE WIRING DIAGRAM

