


CONNECTOR (View from wiring side)		TERMINAL BOARD		PARTS NAME	
W/R	1	J	K	RY5	Starter Relay
R	2	AC1	AC2	RY6	Glow Relay
Y	3	AC3	50	RY7	Engine ON/OFF Relay
BR	4	AC3	19	RY8	Power Relay
B	5	AC3	30	SW9	Starter Switch
W	6	AC3	50	Re3	Rectifier
L	7	AC3	19	PL	Pilot Lamp
O	8	AC3	30		
W/G	9	AC3	50		
Y	10	AC3	19		
BR	11	AC3	30		
W/R	12	AC3	50		
Y	13	AC3	19		
BR	14	AC3	30		
L	15	AC3	50		
W	16	AC3	19		
O	17	AC3	30		
W/G	18	AC3	50		
Y	19	AC3	19		
BR	20	AC3	30		
B	21	AC3	50		
W	22	AC3	19		
L	23	AC3	30		
O	24	AC3	50		
W/G	25	AC3	19		
Y	26	AC3	30		
BR	27	AC3	50		
B	28	AC3	19		
W	29	AC3	30		
L	30	AC3	50		
O	31	AC3	19		
W/G	32	AC3	30		
Y	33	AC3	50		
BR	34	AC3	19		
B	35	AC3	30		
W	36	AC3	50		
L	37	AC3	19		
O	38	AC3	30		
W/G	39	AC3	50		
Y	40	AC3	19		
BR	41	AC3	30		
B	42	AC3	50		
W	43	AC3	19		
L	44	AC3	30		
O	45	AC3	50		
W/G	46	AC3	19		
Y	47	AC3	30		
BR	48	AC3	50		
B	49	AC3	19		
W	50	AC3	30		
L	51	AC3	50		
O	52	AC3	19		
W/G	53	AC3	30		
Y	54	AC3	50		
BR	55	AC3	19		
B	56	AC3	30		
W	57	AC3	50		
L	58	AC3	19		
O	59	AC3	30		
W/G	60	AC3	50		
Y	61	AC3	19		
BR	62	AC3	30		
B	63	AC3	50		
W	64	AC3	19		
L	65	AC3	30		
O	66	AC3	50		
W/G	67	AC3	19		
Y	68	AC3	30		
BR	69	AC3	50		
B	70	AC3	19		
W	71	AC3	30		
L	72	AC3	50		
O	73	AC3	19		
W/G	74	AC3	30		
Y	75	AC3	50		
BR	76	AC3	19		
B	77	AC3	30		
W	78	AC3	50		
L	79	AC3	19		
O	80	AC3	30		
W/G	81	AC3	50		
Y	82	AC3	19		
BR	83	AC3	30		
B	84	AC3	50		
W	85	AC3	19		
L	86	AC3	30		
O	87	AC3	50		
W/G	88	AC3	19		
Y	89	AC3	30		
BR	90	AC3	50		
B	91	AC3	19		
W	92	AC3	30		
L	93	AC3	50		
O	94	AC3	19		
W/G	95	AC3	30		
Y	96	AC3	50		
BR	97	AC3	19		
B	98	AC3	30		
W	99	AC3	50		
L	100	AC3	19		



Wire Size	SYMBOL	COLOR	SYMBOL	COLOR
1.25: 1.25mm <sup>2</sup>	B	BLACK	R	RED
2: 2mm <sup>2</sup>	L	BLUE	W	WHITE
3: 3mm <sup>2</sup>	BR	BROWN	Y	YELLOW
22: 22mm <sup>2</sup>	G	GREEN	LB	LIGHT BLUE
	GR	GRAY	LG	LIGHT GREEN
	V	VIOLET	O	ORANGE
NO MARK: 0.75mm <sup>2</sup>	P	PINK		

# DLW-400ESA4 ENGINE WIRING DIAGRAM

To 1, 2, 3, 4 of CN15 Refer to GENERATOR WIRING DIAGRAM

Refer to GENERATOR WIRING DIAGRAM

To 7, 8, 9 of CN15 Refer to GENERATOR WIRING DIAGRAM

To AC1 of GENERATOR WIRING DIAGRAM

To 5, 6 of CN15 Refer to GENERATOR WIRING DIAGRAM

To CN6, CN43 Refer to GENERATOR WIRING DIAGRAM