




STX-HTX PITCH SYNCHRONIZATION

Using the pitch rocker switches, follow instruction steps 1 - 4

1. **Twin Pitch:** press switch all the way down until you hear the system go over Relief.
2. **Left Pitch Only:** press switch all the way down until you hear the system go over Relief.
3. **Twin Pitch:** press switch all the way up until you hear the system go over Relief.
4. **Left Pitch Only:** press switch all the way up until you hear the system go over Relief.

NOTE: After Synchronization use ONLY the TWIN PITCH switch to pitch blades



As seen from the operators position