

ENGINE COMPONENTS LOCATION & GENERAL DESCRIPTION

Engine Model • Zenith Z428 •

© COPYRIGHT 2020, MULTIQUIP INC, Rev. 1 (10192022)




(1) 15A Fuse (orange wires)
ATM-15 Blade Fuse
Starter Circuit






(2) 5A Fuse (pink wires)
ATM-5 Blade Fuse
12V Ignition Power



Oil Pressure Switch
P/N 201385



Starter Solenoid/Starter
P/N 200423



Ignition Coil Pack
P/N 201334



(1) Cam Position Sensor
P/N 200344
(2) Cam Synch. P/N 201338



Comm. Conn. (Data Link)
"Diagnostic Software Kit"
P/N 202163"



E.C.U.
Engine Control Unit
P/N 201401

ENGINE COMPONENTS LOCATION & GENERAL DESCRIPTION

Engine Model • Zenith Z428 •



16 Pin Connector
#1 Female



Starter Relay 50/30 amp
P/N 200961




Coolant Temp. Sensor
P/N 200526



Bosch Throttle Body
P/N 200704



Low coolant Alarm Switch
P/N 201388



IAT/Map Sensor
P/N 200525



Pre-cat O2 Sensor
P/N 200474



Crank Sensor
P/N 200521


The information and specifications included in this publication were in effect at the time of approval for printing. Illustrations, descriptions, references and technical data contained in this document are for guidance only and may not be considered as binding. Multiquip Inc. reserves the right to discontinue or change specifications, design or the information published in this publication at any time without notice and without incurring any obligations.

ENGINE COMPONENTS LOCATION & GENERAL DESCRIPTION

Engine Model • Zenith Z428 •



Fuel Pump
P/N 201285



Fuel Regulator
P/N 200909




Fuel Filter
P/N 201287



Post-cat O2 Sensor
P/N 201280



3A Fuse
ATM-3 Blade Fuse
Fuel Gauge



30A Fuse
ATM-30 Blade Fuse
Mayco Pump Main

© COPYRIGHT 2020, MULTIQUIP INC, Rev. 1 (10192022)