



# Rammers (HONDA Engine) Maintenance Instructions

The following instructions are intended to assist the user in maintaining Multiquip Rammers with Honda engines. See list below for applicable Models.

**Models:**

- MT-65H
- MT-65HA

Engine/Rammer Maintenance Schedule								
DESCRIPTION	OPERATION	BEFORE EACH USE	FIRST MONTH OR 20 HRS.	FIRST 50 HRS.	EVERY 3 MONTHS OR 50 HRS.	EVERY 6 MONTHS OR 100 HRS.	EVERY 150 HRS.	EVERY YEAR OR 200 HRS.
Engine Oil	CHECK	X						
	CHANGE		X			X		
Air Cleaner	CHECK	X						
	CLEAN				X (1)			
	CHANGE							X
Spark Plug	CHECK-CLEAN					X		
	REPLACE							X
Idle Speed	CHECK-ADJUST							X (2)
Valve Clearance	CHECK-ADJUST							X (2)
Combustion Chamber	CLEAN	After every 300 Hours (2)						
Fuel Tank	CLEAN					X (2)		
Fuel Filter	CHECK					X (2)		
Fuel lines	CHECK	Every 2 years (replace if necessary) (2)						
Pre-cleaner	CLEAN (W/ CLEANING OIL/KEROSENE)						X (1)	
Pre-cleaner Yellow Element	LUBRICATE (2-5 cc SAE-30)						X	
Pre-cleaner Gray Element	LUBRICATE (13-15 cc SAE-30)						X	
Pre-cleaner Paper Filter Element	CLEAN (W/ 30 psi COMPRESSED AIR)						X	
	REPLACE	If Excessively Dirty						
Oil Bath	REPLACE (W/ 1.7 pt. 10W-30SE, SF, OR HIGHER)			X			X	

(1) Service more frequently when used in **DUSTY** areas.

(2) These items should be serviced by your service dealer, unless you have the proper tools and are mechanically proficient. Refer to the HONDA Shop Manual for service procedures.



**MULTIQIP INC.**

POST OFFICE BOX 6254 • CARSON, CA 90749  
 310-537-3700 • 800-421-1244 • FAX: 310-537-3927  
 E-MAIL: mq@multiquip.com • WWW: multiquip.com  
 Montreal, Canada • Manchester, UK  
 Rio De Janeiro, Brazil • Cipsa, Mexico