



Reversible Plate Compactors (YANMAR Engine) Maintenance Instructions

The following instructions are intended to assist the user in maintaining MultiQuip Reversible Plate Compactors with Yanmar engines. See list below for applicable Models.

Models: MVH-150D, MVH-200DS, MVH-306D, MVH-306DS, MVH402DSB

Engine/Plate Compactor Maintenance Schedule								
DESCRIPTION	OPERATION	DAILY (BEFORE OPERATION)	50 HRS. (MONTHLY)	100 HRS.	200 HRS. (EVERY 3 MONTHS)	300 HRS.	400 HRS. (EVERY 6 MONTHS)	1000 HRS. (YEARLY)
Fuel Level	CHECK AND REFILL	X						
Fuel Tank	DRAIN		X					
Fuel Filter	CLEAN				X			
Dual Filter Element	REPLACE						X	
Fuel Oil (ILeak)	CHECK	X (AFTER OPERATION)						
Fuel Injection Nozzle	CHECK						X (1)	
Fuel Injection Pump	CHECK							X (1)
Lube Oil	CHECK LEVEL & REFILL	X						
	REPLACE		X (FIRST TIME)		X			
	CLEAN FILTER		X (FIRST TIME)				X	
	CHECK LEAKS	X (AFTER OPERATION)						
Air Cleaner Element	CHECK				X			
	REPLACE						X	
Spark Arrestor	CHECK FOR CLOGGING	X						
Battery Liquid Level	CHECK & REFILL	X						
Warning Lamps	CHECK	X (WHEN ENGINE IS STARTED)						
Intake and Exhaust Valve Clearance							X (1)	
Compaction Plate	CLEAN	X						
Bolts & Screws	CHECK	X						
Controls	CHECK	X						
Vibrator Oil	CHECK			X				
	REPLACE					X		
Hydraulic System	CHECK FOR LEAKS			X				
Hydraulic Oil	CHECK				X			
V-Belt & Clutch	CHECK				X			

(1) These items should be serviced by your service dealer, unless you have the proper tools and are mechanically proficient. Refer to the YANMAR Shop Manual for service procedures.



MULTIQUIP INC.

POST OFFICE BOX 6254 • CARSON, CA 90749
310-537-3700 • 800-421-1244 • FAX: 310-537-3927
E-MAIL: mq@multiquip.com • WWW: multiquip.com
Montreal, Canada • Manchester, UK
Rio De Janeiro, Brazil • Cipsa, Mexico