



# Trash Pumps (HATZ Engine) Maintenance Instructions

The following instructions are intended to assist the user in maintaining Multiquip Trash Pumps with Hatz engines. See list below for applicable Models.

Models: QP-2TZ, QP-3TZ, MQ41TDH.

Engine/Trash Pump Maintenance Schedule								
DESCRIPTION	OPERATION	BEFORE EACH USE	AFTER EACH USE	FIRST MONTH OR 20 HRS.	EVERY 6 MONTHS OR 100 HRS.	EVERY 250 HRS.	EVERY 500 HRS.	EVERY 1000 HRS.
Engine Oil	CHECK	X						
	CHANGE			X		X		
Engine Oil Filter Element	CHANGE						X	
Oil Filter	CLEAN							X
Water Trap	CHECK	X						
Cooling Air Intake Zone	CHECK	X						
Air Cleaner	CHECK	X						
	CLEAN	X						
	CHANGE						X	
Fuel Filter	REPLACE						X (2)	
Pump	CLEAN		X					
Impeller	CHECK				X			

(2) These items should be serviced by your service dealer, unless you have the proper tools and are mechanically proficient. Refer to HATZ Shop Manual for service procedures.



**MULTIQUIP INC.**

POST OFFICE BOX 6254 • CARSON, CA 90749  
 310-537-3700 • 800-421-1244 • FAX: 310-537-3927  
 E-MAIL: mq@multiquip.com • WWW: multiquip.com  
 Montreal, Canada • Manchester, UK  
 Rio De Janeiro, Brazil • Cipsa, Mexico