



Trash Pumps (ROBIN Engine) Maintenance Instructions

The following instructions are intended to assist the user in maintaining Multiquip Trash Pumps with ROBIN engines. See list below for applicable Models.

Models:

QP-2TE, QP-3TE, QP-40TE, QP-201TA, QP-301TA, QP-40TA

Engine/Trash Pump Maintenance Schedule								
DESCRIPTION	OPERATION	8 HOURS (DAILY)	AFTER 20 HRS.	50 HRS. (WEEKLY)	200 HRS. (MONTHLY)	EVERY 6 MONTHS	500 HRS.	1000 HRS.
Engine	CLEAN	X						
	OVERHAUL							X (1)
Bolts and Nuts	CHECK	X						
Engine Oil	CHECK AND REFILL	X (Refill daily up to upper limit)						
	CHANGE		X	X				
Air Cleaner	CHECK	X						
	CLEAN			X				
Fuel Strainer	CLEAN				X			
Spark Plug	CHECK-CLEAN			X				
	ADJUST				X			
	REPLACE						X	
Valve Clearance	CHECK-ADJUST						X (1)	
Carburetor	CLEAN-ADJUST						X	
Cylinder Head	REMOVE CARBON						X (1)	
Fuel lines	REPLACE	Yearly						
Pump	CLEAN	X (AFTER EACH USE)						
Impeller	CHECK					X		

(1) For procedure, refer to your Robin Engine Service Manual or contact your nearest Robin service dealer.



MULTIQUIP INC.

POST OFFICE BOX 6254 • CARSON, CA 90749
 310-537-3700 • 800-421-1244 • FAX: 310-537-3927
 E-MAIL: mq@multiquip.com • WWW: multiquip.com
 Montreal, Canada • Manchester, UK
 Rio De Janeiro, Brazil • Cipsa, Mexico