

TRANSMITTER PART #1583178 SERVICE PARTS

High/Low Amplitude Part #52010

Start/Stop Switch Part #52077



High/Low Speed Part #52011

Horn Switch Part #1449852

Open top design neoprene boot Part #1415868



Transmitter Vent Part #1430840


Part #4-760213 includes three open top design neoprene boots and the transmitter vent

© COPYRIGHT 2020, MULTIQUIP INC, Rev. 0 (07202021)


The information and specifications included in this publication were in effect at the time of approval for printing. Illustrations, descriptions, references and technical data contained in this document are for guidance only and may not be considered as binding. Multiquip Inc. reserves the right to discontinue or change specifications, design or the information published in this publication at any time without notice and without incurring any obligations.

TRANSMITTER PART #1583178 SERVICE PARTS


© COPYRIGHT 2020, MULTIQUIP INC., Rev. 0 (07202021)



A



B



C

(A) Battery (5 Terminal Connector)
Part #1543722 -Horn Equipped Remotes-

(B) Battery (4 Terminal Connector)
Part #1266872

(C) Drawbar
Part #4-29447

Wall Charger
Part #1504497

Neck Strap
Part #3-10456