



Rammers (ROBIN Engine) Maintenance Instructions

The following instructions are intended to assist the user in maintaining Multiquip Rammers with ROBIN engines. See list below for applicable Models.

Models:

MT-54F, MT-55F, MT-74F, MT-74FA, MT84FA, MT-60HS, MT-62HS, MT-75HS, MT-85HS, MTR-35HS, MTR-40F, MTR-40HS

Engine/Rammer Maintenance Schedule							
DESCRIPTION	OPERATION	8 HOURS (DAILY)	AFTER 20 HRS.	50 HRS. (WEEKLY)	200 HRS. (MONTHLY)	500 HRS.	1000 HRS.
Engine	CLEAN	X					
	OVERHAUL						X (1)
Bolts and Nuts	CHECK	X					
Engine Oil	CHECK AND REFILL	X (Refill daily up to upper limit)					
	CHANGE		X	X			
Air Cleaner	CHECK	X					
	CLEAN			X			
Fuel Strainer	CLEAN				X		
Spark Plug	CHECK-CLEAN			X			
	ADJUST				X		
	REPLACE					X	
Valve Clearance	CHECK-ADJUST					X (1)	
Carburetor	CLEAN-ADJUST					X	
Cylinder Head	REMOVE CARBON					X (1)	
Fuel lines	REPLACE	Yearly					
Pre-cleaner	CLEAN (W/ CLEANING OIL/KEROSENE)				X		
Pre-cleaner Yellow Element	LUBRICATE (2-5 cc SAE-30)				X		
Pre-cleaner Gray Element	LUBRICATE (13-15 cc SAE-30)				X		
Oil Bath	REPLACE (W/ 1.7 pt. 10W-30SE, SF, OR HIGHER)			X (INITIALLY)	X		

(1) For procedure, refer to your Robin Engine Service Manual or contact your nearest Robin service dealer.



MULTIQUIP INC.

POST OFFICE BOX 6254 • CARSON, CA 90749
 310-537-3700 • 800-421-1244 • FAX: 310-537-3927
 E-MAIL: mq@multiquip.com • WWW: multiquip.com
 Montreal, Canada • Manchester, UK
 Rio De Janeiro, Brazil • Cipsa, Mexico